

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PARAGRAPH</u>	<u>PAGE</u>
INTRODUCTION		1
RECORD OF REVISION.....		2, 3
SECTION ONE	DESCRIPTION AND PRINCIPLES OF OPERATION	
GENERAL.....	1-1	4
SYSTEM DESCRIPTION.....	1-2	5
AIR SECTION.....	1-3	6
FUEL REGULATOR SECTION	1-4	7
IDLE SYSTEM.....	1-5	8
MANUAL MIXTURE CONTROL.....	1-6	8
FLOW DIVIDER.....	1-7	9
DISTRIBUTION BLOCK.....	1-8	9
INJECTOR NOZZLES.....	1-9	10
SYSTEM REQUIREMENTS.....	1-10	10
PERFORMANCE.....	1-11	11
SECTION TWO	GETTING STARTED	
CHECKING YOUR SYSTEM.....	2-1	13
OPERATION OF THE INSTALLED SYSTEM	2-2	13
USING THIS MANUAL.....	2-3	13
INSTALLATION OF PIPE THREAD AND O-RING FITTINGS		14
SECTION THREE	INSTALLATION	
FUEL TANKS	3-1	15
AIRFRAME FUEL SYSTEM PLUMBING	3-2	15
FUEL VALVE.....	3-3	16
FUEL FILTERS.....	3-4	16, 17
FUEL BOOST PUMP.....	3-5 - 3-9.....	18 - 21
ENGINE DRIVEN FUEL PUMP.....	3-10, 3-11	22
FUEL PUMP COOLING.....	3-12	22
FUEL PRESSURE GAUGE.....	3-13	23
FUEL LINE CONNECTION	3-14	23
MOUNTING THE FUEL CONTROLLER.....	3-15	23
FUEL INLET CONFIGURATION	3-16	24
METERED FUEL OUTLET CONFIGURATION	3-17	25
MANUAL MIXTURE CONTROL.....	3-18	26
THROTTLE LEVER.....	3-19	27
CONTROLS	3-20	28

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PARAGRAPH</u>	<u>PAGE</u>
SECTION THREE INSTALLATION (CONTINUED)		
AIR INLET	3-21 - 3-23.....	28, 29
FLOW DIVIDER.....	3-24 - 3-27.....	29, 30
DISTRIBUTION BLOCK.....	3-28	30
FLOW METERS	3-29 - 3-32.....	31
NATURALLY ASPIRATED INJECTION NOZZLE	3-33	32
TURBO INJECTOR NOZZLE.....	3-34, 3-35.....	32, 33
BLEED AIR SHUTTLE VALVE	3-36	34
STAINLESS STEEL INJECTION NOZZLE LINES	3-37, 3-38.....	34, 35
TYGOTHANE NOZZLE LINES	3-39	35
PURGE VALVE ASSEMBLY.....	3-40	35, 36
PURGE VALVE INSTALLATION.....	3-41	36, 37
FLUSHING THE FUEL SYSTEM	3-42	37
CHECK LIST FOR FUEL SYSTEM INSTALLATION.....		38
SECTION FOUR GENERAL OPERATING INSTRUCTIONS		
GENERAL.....	4-1	39
STARTING.....	4-2	39
IDLING.....	4-3	39, 40
SHUT DOWN.....	4-4	40
OPERATION USING THE PURGE VALVE	4-5	41
SECTION FIVE FIELD ADJUSTMENTS		
STARTING PROCEDURE.....	5-1, 5-2.....	43 - 45
IDLE SPEED AND MIXTURE ADJUSTMENT	5-3	46 - 48
FULL THROTTLE MIXTURE ADJUSTMENT	5-4	48 - 50
INSTRUCTIONS FOR USING THE PURGE VALVE	5-5	50, 51
SECTION SIX TROUBLESHOOTING		
TROUBLESHOOTING.....	6-1, 6-2.....	53
TROUBLESHOOTING CHARTS.....		54 - 59
TESTING FOR AIR IN THE FUEL SYSTEM	6-3	60, 61
CORRECT OPERATION OF THE FUEL CONTROLLER	6-4	61 - 63
IDLE VALVE LEAKAGE.....	6-5	63, 64
MANUAL MIXTURE CONTROL LEAKAGE TEST	6-6	64, 65
TESTING INJECTOR NOZZLES	6-7	65, 66
NOZZLE CLEANING INSTRUCTIONS.....	6-8	67

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PARAGRAPH</u>	<u>PAGE</u>
SECTION SIX TROUBLESHOOTING (CONTINUED)		
TESTING THE FLOW DIVIDER	6-9	68
FLOW DIVIDER CLEANING INSTRUCTIONS	6-10	69, 70
INTERMITTENT POWER LOSS	6-11	70, 71
SECTION SEVEN INJECTION SYSTEM NOTES		
INDUCTION SYSTEM ICING	7-1	73
VAPORIZATION ICING	7-2, 7-3	73
ATMOSPHERIC ICING	7-4	73
ICE AND SNOW	7-5	73
FLIGHT DURING ADVERSE WEATHER CONDITIONS	7-6	74
SECTION EIGHT MAINTENANCE, LUBRICATION, AND STORAGE		
MAINTENANCE	8-1 - 8-3	75, 76
LUBRICATION	8-4, 8-5	76
PREPARATION FOR STORAGE	8-6	76, 77
SECTION NINE OVERHAUL PERIOD		
TIME BETWEEN OVERHAUL	9-1, 9-2	79
PREPARATION FOR SHIPMENT	9-3 - 9-5	79, 80
APPENDIX A		
FUEL SYSTEM SCHEMATICS		A-1 - A-26
APPENDIX B		
FUEL CONTROLLER INSTALLATION		B-1 - B-14
APPENDIX C		
AIR INLET		C-1 - C-10
APPENDIX D		
FLOW DIVIDER INSTALLATION		D-1 - D-4

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PARAGRAPH</u>	<u>PAGE</u>
APPENDIX E		
DISTRIBUTION BLOCK INSTALLATION		E-1, E-2
APPENDIX F		
BLEED AIR NOZZLE RAIL		F-1, F-6
APPENDIX G		
BLEED AIR SHUTTLE VALVE		G-1, G-2
APPENDIX H		
NOZZLE LINE INSTALLATION		H-1 - H-6
APPENDIX I		
PURGE VALVE INSTALLATION		I-1 - I-8
APPENDIX J		
INTAKE MANIFOLD CONSIDERATIONS		J-1 - J-5
APPENDIX K		
FM-100A, FM-150, FM-150L, FM-200A, FM300B, FM R Series		K-1 – K-19
FOLD OUT PAGE		
FM-SERIES FUEL INJECTION SCHEMATIC		Fold out