



INSTALLATION

AND

SERVICE MANUAL

9003

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PARAGRAPH</u>	<u>PAGE</u>
INTRODUCTION		1
RECORD OF REVISION.....		2, 3
SECTION ONE	DESCRIPTION AND PRINCIPLES OF OPERATION	
GENERAL.....	1-1	4
SYSTEM DESCRIPTION.....	1-2	5
AIR SECTION.....	1-3	6
FUEL REGULATOR SECTION	1-4	7
IDLE SYSTEM.....	1-5	8
MANUAL MIXTURE CONTROL.....	1-6	8
FLOW DIVIDER.....	1-7	9
DISTRIBUTION BLOCK.....	1-8	9
INJECTOR NOZZLES.....	1-9	10
SYSTEM REQUIREMENTS.....	1-10	10
PERFORMANCE.....	1-11	11
SECTION TWO	GETTING STARTED	
CHECKING YOUR SYSTEM.....	2-1	13
OPERATION OF THE INSTALLED SYSTEM	2-2	13
USING THIS MANUAL.....	2-3	13
INSTALLATION OF PIPE THREAD AND O-RING FITTINGS		14
SECTION THREE	INSTALLATION	
FUEL TANKS	3-1	15
AIRFRAME FUEL SYSTEM PLUMBING	3-2	15
FUEL VALVE.....	3-3	16
FUEL FILTERS.....	3-4	16, 17
FUEL BOOST PUMP.....	3-5 - 3-9.....	18 - 21
ENGINE DRIVEN FUEL PUMP.....	3-10, 3-11	22
FUEL PUMP COOLING.....	3-12	22
FUEL PRESSURE GAUGE.....	3-13	23
FUEL LINE CONNECTION	3-14	23
MOUNTING THE FUEL CONTROLLER.....	3-15	23
FUEL INLET CONFIGURATION	3-16	24
METERED FUEL OUTLET CONFIGURATION	3-17	25
MANUAL MIXTURE CONTROL.....	3-18	26
THROTTLE LEVER.....	3-19	27
CONTROLS	3-20	28

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PARAGRAPH</u>	<u>PAGE</u>
SECTION THREE INSTALLATION (CONTINUED)		
AIR INLET	3-21 - 3-23.....	28, 29
FLOW DIVIDER.....	3-24 - 3-27.....	29, 30
DISTRIBUTION BLOCK.....	3-28.....	30
FLOW METERS	3-29 - 3-32.....	31
NATURALLY ASPIRATED INJECTION NOZZLE	3-33.....	32
TURBO INJECTOR NOZZLE.....	3-34, 3-35.....	32, 33
BLEED AIR SHUTTLE VALVE	3-36.....	34
STAINLESS STEEL INJECTION NOZZLE LINES	3-37, 3-38.....	34, 35
TYGOTHANE NOZZLE LINES	3-39.....	35
PURGE VALVE ASSEMBLY.....	3-40.....	35, 36
PURGE VALVE INSTALLATION.....	3-41.....	36, 37
FLUSHING THE FUEL SYSTEM	3-42.....	37
CHECK LIST FOR FUEL SYSTEM INSTALLATION.....		38
SECTION FOUR GENERAL OPERATING INSTRUCTIONS		
GENERAL.....	4-1.....	39
STARTING.....	4-2.....	39
IDLING.....	4-3.....	39, 40
SHUT DOWN.....	4-4.....	40
OPERATION USING THE PURGE VALVE	4-5.....	41
SECTION FIVE FIELD ADJUSTMENTS		
STARTING PROCEDURE.....	5-1, 5-2.....	43 - 45
IDLE SPEED AND MIXTURE ADJUSTMENT	5-3.....	46 - 48
FULL THROTTLE MIXTURE ADJUSTMENT	5-4.....	48 - 50
INSTRUCTIONS FOR USING THE PURGE VALVE	5-5.....	50, 51
SECTION SIX TROUBLESHOOTING		
TROUBLESHOOTING.....	6-1, 6-2.....	53
TROUBLESHOOTING CHARTS.....		54 - 59
TESTING FOR AIR IN THE FUEL SYSTEM	6-3.....	60, 61
CORRECT OPERATION OF THE FUEL CONTROLLER	6-4.....	61 - 63
IDLE VALVE LEAKAGE.....	6-5.....	63, 64
MANUAL MIXTURE CONTROL LEAKAGE TEST	6-6.....	64, 65
TESTING INJECTOR NOZZLES	6-7.....	65, 66
NOZZLE CLEANING INSTRUCTIONS.....	6-8.....	67

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PARAGRAPH</u>	<u>PAGE</u>
SECTION SIX	TROUBLESHOOTING (CONTINUED)	
TESTING THE FLOW DIVIDER	6-9	68
FLOW DIVIDER CLEANING INSTRUCTIONS	6-10	69, 70
INTERMITTENT POWER LOSS	6-11	70, 71
SECTION SEVEN	INJECTION SYSTEM NOTES	
INDUCTION SYSTEM ICING	7-1	73
VAPORIZATION ICING.....	7-2, 7-3.....	73
ATMOSPHERIC ICING	7-4	73
ICE AND SNOW.....	7-5.....	73
FLIGHT DURING ADVERSE WEATHER CONDITIONS	7-6.....	74
SECTION EIGHT	MAINTENANCE, LUBRICATION, AND STORAGE	
MAINTENANCE	8-1 - 8-3.....	75, 76
LUBRICATION	8-4, 8-5.....	76
PREPARATION FOR STORAGE.....	8-6	76, 77
SECTION NINE	OVERHAUL PERIOD	
TIME BETWEEN OVERHAUL.....	9-1, 9-2.....	79
PREPARATION FOR SHIPMENT	9-3 - 9-5.....	79, 80
APPENDIX A		
FUEL SYSTEM SCHEMATICS		A-1 - A-26
APPENDIX B		
FUEL CONTROLLER INSTALLATION.....		B-1 - B-14
APPENDIX C		
AIR INLET		C-1 - C-10
APPENDIX D		
FLOW DIVIDER INSTALLATION.....		D-1 - D-4

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PARAGRAPH</u>	<u>PAGE</u>
APPENDIX E		
DISTRIBUTION BLOCK INSTALLATION		E-1, E-2
APPENDIX F		
BLEED AIR NOZZLE RAIL		F-1, F-6
APPENDIX G		
BLEED AIR SHUTTLE VALVE		G-1, G-2
APPENDIX H		
NOZZLE LINE INSTALLATION		H-1 - H-6
APPENDIX I		
PURGE VALVE INSTALLATION		I-1 - I-8
APPENDIX J		
INTAKE MANIFOLD CONSIDERATIONS		J-1 - J-5
APPENDIX K		
FM-100A, FM-150 , FM150-C, FM-150L, FM-200A, FM-200C, FM300B, FM R Series...	K-1 – K-20

INTRODUCTION

This manual has been prepared and distributed by Airflow Performance Inc. It is intended to be used by personnel responsible for the installation, adjustment, and maintenance of Fuel Injection Systems.

Periodic revisions will be made to this manual to incorporate the latest information and procedures. If the reader finds any information or procedures omitted, please direct your comments and suggestions to Airflow Performance. An effort will be made to include this information in future revisions.

NOTE

Airflow Performance products are not approved for use on certified aircraft. It is the users responsibility for using aircraft approved installation methods and materials to insure correct and safe operation of the engine and aircraft. Information in this manual DOES NOT supersede any published airframe/engine manufacture publication. Conflicting information should be directed to Airflow Performance.

This manual is compiled with special thanks and dedicated to:

Elmer Haase
Jim Kirwin
R.G. Moore

of the Bendix Energy Controls Division
South Bend, Indiana

© 1998 Airflow Performance, Inc. PO Box 3364 Spartanburg, SC 29304
864-576-4512

RECORD OF REVISION

DATE	DESCRIPTION
July 2000	Manual Revision A
May 2001	Manual Revision B Section 3 and Appendix D
August 2001	Manual Revision C Section 4, page 35
June 2004	Manual Revision D Section 3, pages 14, 16, 19, 26, 32 Section 4, page 34 Section 5, pages, 37, 42, 44, 45 Section 6, pages 53, 65 Appendix C Revision B, page C-1 Appendix I Revision B ,page I-1
June 2006	Manual Revision E Section 1, pages 4, 5 Section 2, page 11 Section 3,pages 15, 17, 18, 21, 29, 35 Section 4 page 39 Section 5 pages 41, 48, 49 Appendix B Revision B, pages B-6, B-7, B-8 Appendix C Revision C, page C-7 Appendix F Revision B, page F-3 Appendix I Revision C, pages I-1, I-4, I-5
September 2008	Manual Revision F Section 1, page 8 Section 2, page 11 Section 3, pages 16, 17, 19, 22-25, 24, 25, 28, 30, 31 Section 4, page 38 Section 6, pages 52, 67, 68 Section 8, page 74 Appendix A Revision C, page A-24 Appendix B Revision C, pages B-9, B-10 Appendix C Revision D, page C-8 Appendix E Revision B, page E-2 Appendix F Revision C, page F-4 Appendix I Revision D, pages I-5, I-6
November 2010	Manual Revision G Section 3, page 16, 17, 23, 38 Section 4, page 41 Section 9, page 79 Appendix B Revision D, page B-10, B-11

RECORD OF REVISION

DATE	DESCRIPTION
November 2010	Manual Revision G Appendix C Revision E, page C-8, C-9 Appendix F Revision D, page F-5, F-6-
February 2016	Manual Revision H Table of Contents Revision H, page iii, iv Section 1, page 10 Section 3, page 16, 18, 20, 27, 31 Appendix A Revision D, page A-3, A-4, A-5, A-15, A-25 Appendix B Revision E, page B-12, B-13 Appendix D Revision C, page C-3, C-4 Appendix K, page K1 – K-18
May 2017	Manual Revision I Table of Contents Revision I page iv Installation of Pipe Thread and O-Ring Fittings, page 14 Section 3, pages 32, 33 Section 5, page 48 Section 8, pages 75, 76 Appendix K Rev. A, pages K 1, K 6, K 9
April 2023	Manual Revision J Installation of Pipe Thread and O-Ring Fittings, page 14 Revise fitting torque values, add torque values for steel lock nuts. Appendix Rev B. Pages K1, K3, K4. Addition of “C” series models.


THIS PAGE INTENTIONALLY LEFT BLANK

SECTION ONE

DESCRIPTION AND PRINCIPLES OF OPERATION

GENERAL

- 1-1. The FM-series fuel injection system uses the proven principle of mass airflow metering to proportion the fuel flow to the engine. Since the system requires the inlet fuel to be under pressure, installation position and external g-forces during operation do not effect its metering performance. All models of the FM injector operate on the same principle.



Only the throttle bore varies in size depending upon the horsepower application for which it is used. This system has successfully been used on two stroke, four stroke and rotary type internal combustion engines. Models of this injection system are capable of running naturally aspirated engines of 65 to 800 horsepower. Higher horsepower would be attainable using the same size unit by turbo or supercharging. Multiple units can be used when required.


SYSTEM DESCRIPTION

- 1-2. The FM-series system is a mass airflow device employing a venturi to generate a signal corresponding to the mass airflow, depending upon engine requirements. Metered fuel is constant flow (Refer to the attached schematic).

DESCRIPTION AND PRINCIPLES OF OPERATION

AIR SECTION


1-3. The air section consists of a throttle body containing the air control throttle valve and necessary linkage, the regulator mounting pad and a center mounted bullet type venturi with a boost venturi. By employing this type of venturi, a venturi signal can be generated at low air flows while maintaining a low pressure loss across the venturi at higher air flows. This signal to loss ratio is called gain. Typically a venturi of this type has a gain of five while a side wall or conventional type venturi has a gain of two. A measure of the air flow consumption of the engine is accomplished by sensing inlet air pressure and venturi throat pressure in the throttle body. These pressures are vented to two sides of the air diaphragm. This pressure signal is called metering suction differential (MSD). By movement of the throttle valve, a change in the engine air consumption occurs that will change the velocity of the air through the venturi, which will reflect an immediate change in the MSD.



High gain
bullet venturi

side wall venturi


venturi has a



DESCRIPTION AND PRINCIPLES OF OPERATION

FUEL REGULATOR SECTION

- 1-4. The fuel section consists of the regulator and jetting systems. The regulator consists of an air diaphragm and a fuel diaphragm connected by a solid regulator valve stem. The MSD is applied across the air diaphragm to produce a force to open the fuel regulator ball valve. The fuel flowing through the metering jet takes a pressure drop (metering head, MH) and this pressure differential is applied across the fuel diaphragm to produce an equal and opposite force across the fuel diaphragm, which tends to close the regulator ball valve. The regulator will thus find an equilibrium condition from these forces. Since the laws of flow apply to both air and fuel systems, the fuel flow generated by the regulator is proportional to air flow. Fuel air ratio is varied by changing the area of the metering jet. Response time of the regulator for a change in airflow will give a resulting change in fuel flow within 0.05 seconds. This quick response time, together with the injector nozzles located near the intake valves, eliminates the need for an acceleration pump.




DESCRIPTION AND PRINCIPLES OF OPERATION

IDLE SYSTEM

- 1-5. Fuel flow is controlled below 20% power by a rotary idle valve linked to the throttle valve. In the idle regime, the venturi signal is negligible and the MSD generated is not sufficient to accurately operate the regulator. To create a positive MH, a constant effort spring is used to generate the required force. Engine idle air flow requirements are controlled by an idle speed adjustment screw located on the throttle stop lever. Idle mixture is set by use of an adjustable idle linkage. Off idle fuel mixture is controlled by the idle valve slot contour.

MANUAL MIXTURE CONTROL

- 1-6. The full rich setting incorporated in the fuel controller satisfies the engine requirements for sea level operation. As air density decreases, the velocity of air increases through the fuel controller throttle body to maintain the same weight of air into the engine. This will increase the air metering forces and in turn increase the fuel metering forces resulting in a richer fuel air ratio as altitude increases. The actual change in fuel air ratio varies as the square root of the change in ambient air density. Variation in fuel flow for this type of system with changes in air density is approximately 1/2 the change of a fuel system using RPM and throttle angle parameters. The rotary manual mixture control valve produces a full rich condition when the lever side stamped "R" (rich) is against the stop. A progressively leaner mixture is attained as the lever is moved toward the idle cut off ("ICO") position. While the ICO position will normally shut the engine down it does not provide zero leak ICO. With mixture control lever side stamped "ICO" against the stop, there is approximately 1.0 to 3.0 pound per hour (PPH) leakage across the mixture control valve.



Mixture control shown in idle cut off (ICO) position

DESCRIPTION AND PRINCIPLES OF OPERATION

FLOW DIVIDER

- 1-7. Metered fuel is delivered from the fuel controller to the flow divider. Its purpose is to divide the metered fuel equally to each injection nozzle at idle regardless of their height between each other. At idle, nozzle back pressure is typically 1-5 inches of gas pressure, if there is a difference in height between the nozzles then idle flow will tend to flow out the lowest nozzles. Metered fuel pressure enters the flow divider through a channel that permits fuel to pass through the I.D. of the flow divider spool valve. At idle the fuel pressure from the fuel controller must build up to overcome the spring force applied to the diaphragm and spool valve. This moves the spool valve upward to allow fuel to pass through the calibrated slots in the bottom of the flow divider bushing. Since the fuel controller meters and delivers a fixed amount of fuel to the flow divider, the spool valve will only open as far as necessary to pass the amount of fuel to the nozzles. Since it takes approximately 1.75-3 PSI pressure to open the spool valve, the fuel will accurately be divided between the nozzles if there is a difference in height between them of 70 inches. At idle the nozzle discharge pressure is negligible, the opening of the spool valve to the slots is very small, and thus the fuel is divided for the individual cylinders at this point by the flow divider. The flow divider also keeps the metered fuel under pressure and shuts off the individual nozzle ports when the fuel controller is placed in "idle cutoff".



DISTRIBUTION BLOCK

- 1-8. For installation where the engine and or injector nozzles are mounted in a horizontal plane, a distribution block can be used. This device has a common manifold that all the nozzle lines are connected to. The block incorporates a pressurizing valve to provide back pressure on the fuel controller regulator. This keeps the metered fuel hose from draining when the engine is shut off. The distribution block must be mounted below the injector nozzles to keep the nozzle lines from draining and give good idle performance to the engine. Distribution blocks are manufactured in 4, 6, and 8 cylinder designs.



DESCRIPTION AND PRINCIPLES OF OPERATION

INJECTOR NOZZLES

- 1-9. Fuel injection nozzles for each cylinder are of the air bled type. This type of nozzle uses the pressure differential between ambient and manifold pressure to draw air into the nozzle mixing chamber and spray an atomized fuel-air charge at the intake valve. Each nozzle incorporates a calibrated fuel restrictor (jet), the size of which is determined by; 1) the fuel pressure available at maximum horsepower, 2) the total fuel flow required at maximum horsepower, and 3) the number of injector nozzles used on the engine. The fuel restrictors are calibrated to flow alike within plus or minus 1%. The nozzles are interchangeable between engine and cylinders, assuming the restrictors are the same size. There are four standard sizes of restrictors. .015 designated by three bands machined on the restrictor, .022; designated by one machined band on the restrictor, .028, designated by no (smooth) band on the restrictor and .032, designated by two bands machined on the restrictor. Special restrictors are made to tune individual cylinder EGT. These are designated by the size of the restrictor or a + % or - % showing the amount the restrictor is rich or lean from the standard calibration.



NOTE

Airflow Performance injector nozzle restrictors are described above. Bendix / Precision restrictors are similar but their restrictor has one band on the restrictor body and are made from stainless steel. This is a .028 restrictor.



Restrictor marked with size

SYSTEM REQUIREMENTS

- 1-10. The minimum fuel pressure requirement for system operation is dependent upon the injector nozzle drop, intake manifold pressure and the pressure requirement for regulator operation. The control is insensitive to inlet fuel pressure variation. Normal operating fuel inlet pressures are typically 20-90 PSIG. The control is compatible for use with all types of gasoline, alcohol and alcohol based fuels. When using alcohol the control system should be flushed with gasoline or equivalent to prevent gummy deposits and corrosion (common when using methanol) on internal parts. This should be done when the injector will be out of service for more than one week. Satisfactory operation of the fuel injection system depends on the fuel being relatively free of contamination. Fuel filtration before entering the control should be at least 125 microns.

DESCRIPTION AND PRINCIPLES OF OPERATION

PERFORMANCE

- 1-11. Response time of the regulator for a change in airflow will give a resulting change in fuel flow within 0.05 seconds. This quick response time, together with the fuel nozzles located near the intake or reed valves, eliminates the need for an acceleration pump. The injector is a non-compensated unit and therefore its fuel metering will be affected by changes in air density. This change in fuel air ratio varies as the square root of the change in ambient air density. Variation in fuel flow for this system with changes in air density is approximately 1/2 the change of a fuel system using RPM and throttle angle parameters.

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION TWO

GETTING STARTED

CHECKING YOUR SYSTEM

- 2-1. Unpack your shipment and check all parts against the packing list. If any parts or components are damaged or missing contact Airflow Performance immediately. Fuel controllers and components have been configured for a specific installation. Even so, specific installations may differ. If you are unsure of your specific installation, please call our engineers at the factory if you require a different configuration for your components to fit correctly.

OPERATION OF THE INSTALLED SYSTEM

- 2-2. There are many factors affecting satisfactory fuel injection operation in service, which cannot be addressed regarding the design of the fuel controller alone. A recognition of these requirements regarding fuel tanks, fuel lines, fuel pumps, fuel pressure requirements, controls, air induction inlet, intake manifold design, and the operation and maneuvers the aircraft will be subjected to, must be evaluated if the fuel injection system is to function successfully in the airplane.

WARNING

It is up to the owner/installer to use proper and approved aircraft installation and fabrication techniques. Airflow Performance recommends using AC-4313-2B as a guide for approved methods and techniques for installing components on aircraft installations. Incorrect installation, modification, failure to lockwire appropriately of the supplied parts can result in poor engine operation, sudden stoppage or failure of the engine. Damage injury or death may occur. Airflow Performance is not responsible for any use of this product. If there are questions about the installation or use of this product, consult a qualified mechanic.

USING THIS MANUAL

- 2-3. This manual is intended as a guide to installing your fuel injection system. There are many different installation possibilities. **There are some important details to pay attention to, and these items are discussed in the following sections.** We have attempted to show some of the combinations for installing the system and the related components. You may encounter a different situation than is explained in this manual. If you are unsure of the procedure or correct components to use in your particular situation, call our engineers at the factory to discuss the installation situation you have encountered.

INSTALLATION OF PIPE THREAD AND O-RING FITTINGS

The torque values listed are recommended values, these DO NOT supersede any published airframe/engine manufacture publication.

PIPE THREAD FITTINGS

- DO NOT under any circumstance use Teflon tape.
- Approved sealants are Permatex Thread Sealant #14 or Loctite 565 PST.

Recommended Pipe Thread Torque Values

- Torque 1/8” NPT fittings to 45 – 65 inch pounds.
- Torque 1/4” NPT fittings to 70 – 110 inch pounds.

O-RING FITTINGS and AN FITTINGS

- DO NOT under any circumstance use pipe thread sealant, “Gas Tite”, “Fuel Lube” or Teflon tape on O-ring fittings. No sealant of any kind is required on flared fittings or B-Nuts.
- Apply a film of motor oil to the O-ring before installing the fitting.

Recommended O-Ring and Flared Fitting Torque Values

- #4 Plugs 30–50 in-lbs., #4 Hose B-Nut 65-115 in-lbs., #4 Bulkhead Nut 95-150 in-lbs.
- #6 Plugs 50–70 in-lbs., #6 Hose B-Nut 135-160 in-lbs., #6 Bulkhead Nut 150-200 in-lbs.
- #8 Plugs 60–90 in-lbs., #8 Hose B-Nut 260-300 in-lbs., #8 Bulkhead Nut 280-330 in-lbs.
- If the fitting leaks around the O-ring seat, replace the O-ring, inspect the O-ring port for scratches or nicks.
- If fitting leaks around flare fittings inspect the flare for scratches, or improper flare. Inspect the AN fitting for nicks or dents on the taper of the fitting where the flare seats.
- When installing bulkhead fittings. Insure that the O-ring is on the smooth part of the fitting when the bulkhead nut is tightened.

STEEL LOCK NUTS

- 10-32 Steel Lock Nuts (MS21045-3) 25-30 in-lbs.
- 1/4-28 Steel Lock Nut (MS21045-4) 50-70 in-lbs. (MS21042-4 Mixture Control) 30-40 in-lbs.
- 5/16-24 Steel Lock Nut (MS21045-5) 110-115 in-lbs. (MS21042-5 Throttle Shaft) 50-60 in-lbs.

INSTALLING STUDS

When installing studs measure the complete stack-up of the parts to be clamped plus the lock nut and washer. Provide an additional 1 1/2 threads to be exposed above the lock nut, this is the exposed measured distance. Installation on the stud into the casting is minimum 1 1/2 diameters of the stud OD thread (5/16” stud = .47 engagement of the threads minimum). Use Loctite 620 to install the stud in the casting to the measured exposed distance.

SECTION THREE

INSTALLATION

Refer to Appendix 'A' for fuel system schematics and fuel pump installations.

FUEL TANKS

- 3-1. Fuel tanks must be located and designed to provide unobstructed fuel flow to the fuel system. Tank outlets should have finger screens on the fuel outlets to protect the fuel pumps in the system. Fuel pick-ups in the tank should be designed so that no air can be picked up with the fuel. Insure that fuel can be picked up when the aircraft is in unusual attitudes. Sumps located at the fuel pick-up and baffles should be incorporated in the tank design to provide non-aerated fuel pick-up. If fuel return ports are installed in the tank, their location should be such that it does not influence the fuel pick-up, or aerate the fuel in the tank. Inverted fuel systems must provide unobstructed fuel pick-up in all attitudes. Insure the design of the flop tube and mechanism is free to swing and will not introduce air into the fuel. Fuel tank venting is very important. Insure that the vent system is adequate for the fuel flow requirements. What may seem to be a good scheme for venting the tanks on the ground may actually pull a vacuum on the tanks in flight. It is wise to have positive or ram air pressure on the venting system in flight. Fuel outlets must be sized correctly for the fuel flow requirements of the system. This is affected by the type of fuel pumping system used. A returning type or loop system will require larger feed ports than a non returning system since the total fuel flow will be greater than the engine requirements. There must be no restriction to the fuel flow exiting the tank. Consult Airflow Performance if you are unsure of the fuel outlet ports in your fuel tanks for your application.

AIRFRAME FUEL SYSTEM PLUMBING

- 3-2. Typically all plumbing in the airframe is done in aluminum tubing. This saves weight, provides a smooth flow path and makes for a sanitary installation. Insure that the tubing is the correct size for the fuel system. A common practice is to use 3/8" diameter tubing (.375 dia.) for aircraft having engines up to 325 HP. For installations where the engine will produce over 325 HP, 1/2" diameter tubing (.500 dia.) should be used. Consideration for the type of fuel system (returning or non-returning) and the length of the tubing required, will also be a factor in determining the size of the fuel feed tubing in the airframe. Using tube flaring tools with serrated jaws are not acceptable. Use only aircraft grade flaring equipment.

INSTALLATION

FUEL VALVE

- 3-3. A fuel shut-off valve should be installed in the airframe fuel system plumbing. This valve usually incorporates the fuel selector valve if multiple fuel tanks are used. The valve should provide free flow to the fuel with no restriction and give zero leak in the off position. This feature is needed to allow service to the components of the fuel system. A high quality ball type valve is desirable for this use. If a fuel return is used in the system, the fuel selector valve should switch the return fuel to the tank from which the fuel is drawn. There are other methods for simple fuel management. A small sump or surge tank can be used to feed the main tanks into via the selector valve. The return fuel can be put into this tank thus eliminating the need to return the fuel to the selected tank. As per section 3-1 insure that the surge tank will provide adequate flow to the pump system, will not air lock and that the main tanks will maintain adequate feed rate to keep the surge tank full under all conditions of power and aircraft attitude.


FUEL FILTERS

- 3-4. A fuel filter should be installed in the system before the fuel boost pump, and after the selector valve. The filter may also incorporate a gascolator. If this type of device is used, then the gascolator should be installed at the lowest point in the fuel system. Gascolators are not required for proper operation of the fuel injection system but if used, should not be installed on the engine side of the firewall. Airflow Performance **does not** approve the use of **any** paper element type fuel filter as the primary filter in the aircraft. Paper element filters will restrict the inlet of the fuel pumps due to their fine filtration and their susceptibility to clogging from picking up water. If the inlet of the fuel pumps are restricted, the pressure on the inlet becomes depressed, this will cause the fuel to boil and the vapor will flow into the fuel controller causing it to malfunction. This problem is not as evident when float carburetors are used, since the float chamber will allow the fuel vapor and bubbles to escape. A screen type filter should be used. The filter size must be based on the total fuel flow through it, not just the engine fuel consumption. This again depends upon the type of fuel system in the aircraft, returning or non-returning. The filter Airflow Performance recommends for this application is P/N 1090079. This a maintainable filter incorporating a 125 micron pleated stainless steel filter element with a anodized aluminum housing. The filter should be in stalled in the aircraft so that periodic cleaning can be performed. It can be clamped by using -26 Adel clamps around the filter body to support it securely to the airframe structure. It is recommended that the filter be installed on the cool side of the firewall. No other filters are necessary in the system. In certain applications specifically with aircraft with composite or fiberglass fuel tanks, additional filtration may be required. In these applications it is recommended that a filter of 10-25 microns be installed after the boost pump to filter out composite debris. The filter must be of adequate size to prevent clogging and is placed down stream of the boost pump so that the boost pump can force fuel through it.



P/N 1090079 Maintainable Fuel Filter

INSTALLATION



The filter can be cleaned periodically by removing the filter from the fuel system, un-screwing the end cap of the filter assembly with a 1 1/2" wrench while holding the other side of the housing with a 1 3/8" wrench or vise. The filter should be inspected after 5-10 hours of operation on new installations and then typically every year at the condition inspection after that. Inspect more frequently if known fuel conditions are questionable. The filter element can be removed from the filter cap and cleaned in mineral spirits then blown dry with compressed air. Inspect the seal O-rings. These may be re-used if in satisfactory condition. Re-assemble the filter using some engine oil on the O-rings. Make sure the conical spring is installed as per the picture and the filter assembly is installed back in the fuel system in the correct flow direction as designated by the arrows on the filter housing.



Standard Fuel Inlet



90 Deg. Fuel Inlet



Side Mount Fuel Inlet

The fuel controller incorporates a 75 micron filter in the fuel inlet fitting. If you are unsure of the type of fuel filtration to use for your application, contact Airflow Performance. This is a very important component of the fuel system and will effect the correct operation of the fuel injection system if sized incorrectly. All Airflow Performance fuel filters are non-relieving type.

INSTALLATION

FUEL BOOST PUMP


- 3-5. A fuel boost pump is required for engine starting and as an emergency back-up to the engine driven pump. The pump must produce the pressure and flow required to support the engine fuel requirements at maximum HP in the event of an engine driven pump failure. Weldon and Dukes pumps (these are common boost pumps used on certified aircraft) can be installed in line since these pumps incorporate integral bypass and relief valves. The relief valve on the boost pump should be set a few PSI higher than the engine driven pump operates at to verify that the boost is running when it is turned on. Ideally the boost pump should be installed in the system so that under normal flight attitudes the pump inlet will be gravity fed from the fuel supply. If this condition can not be satisfied, check with the manufacture of the boost pump to determine the dry suction lift capability of the pump. Making the pump draw fuel will increase the possibility of getting fuel vapor or bubbles in the fuel system, causing malfunction of the fuel controller, and can cause premature failure of the boost pump.
- 3-6. It is recommended that the boost pump is mounted in the aircraft behind the firewall. This will keep the pump in a cooler environment and will tend to keep vapor lock and hot operation problems to a minimum. In installations where the boost pump must be mounted on the firewall, it advisable to enclose the pump package in a box and flow blast air through the box. This will keep cooling air flowing through the box in flight and minimize heat soak during shut down. If the gascolator is located on the firewall it should also be installed in the box.
- 3-7. The Airflow Performance auxiliary pump, P/N 2090255 uses a high pressure roller vane type fuel pump. This pump package incorporates an intergral relief / bypass valve. This provides a simple in and out connection to the pump. The relief valve allows circulation of fuel through the pump to keep the pump motor cool and sets the pressure to the system at 25-32 PSI. A bypass check valve is incorporated so that when the aux. pump is not running, fuel will bypass the boost pump and flow directly to the engine driven fuel pump without restriction. This pump package will draw 5 amps at 12 VDC. The pump should be protected by a 7 to 10 amp circuit breaker. Electrical wiring to the pump should be a minimum of 16 gauge stranded wire. The pump is supplied with 14 gauge wire. The red wire is connected to +12 VDC the black wire is connected to airframe ground. Mount the pump package by using MS21919WDG29(cushion clamps) clamps around the pump body and or the relief valve housing to support it securely to the airframe structure. If two clamps are placed around the pump body, it may be necessary to trim the rubber on the outside of the clamp to provide clearance between the pump motor and the bypass valve.




INSTALLATION

All Airflow Performance pumps are continuous duty. The maximum dry suction lift of this pump is 2 feet. It is recommended that the pump be mounted as low as possible to the fuel supply to insure quick priming and minimize vapor problems. A flooded inlet is preferred.

Some pump packages are available with an integral relief return line plumbed to the inlet of the pump. The example shown is an assembly for the M-14P radial engine. It has -8 AN fittings for the inlet and out let.



3-8. There are some installations where no engine driven fuel pump is used. In this case a dual electric pump package should be used. The pumps should be connected to separate electrical supplies to provide a redundant pump in case of a primary electrical system failure. The pumps incorporate internal check valves to prevent fuel from flowing backward through the inactive pump. The pump package can be mounted using 3 MS21919WDG29 (cushion clamps). Secure two clamps to one pump motor and one clamp to the other pump motor.



NOTE:


To insure a quick prime of fuel to the electric pump, on initial start, disconnect the outlet end of the pump and attach a suitable piece of hose. Put the hose in a container to catch the fuel. Energize the pump. This will allow the pump to free flow. Let it run to pass ½ to 1 gallon of fuel. De-energize the pump, and re-connect the standard aircraft plumbing.

INSTALLATION

WARRANTY OF PUMP PACKAGES

All pump packages are tested in house to insure proper operation of the pump motor; correct pressure out put, correct flow out put and the assembly has been tested for external leakage.

- There will be no warranty on the pump motor P/N HW-3801.
 - Do not run this pump without fuel.
 - Water contamination will ruin the pump.
- Removing the supplied electrical wires will void the warranty.
- Removing or changing the supplied pump package fittings will void the warranty.
- If the supplied pump inlet or outlet fittings do not fit your installation, please contact Airflow Performance, Inc.



INSTALLATION

CHECK LIST FOR BOOST PUMP INSTALLATION

1. Flush airframe fuel system plumbing before connecting the high-pressure boost pump.

Use an inexpensive low-pressure fuel pump and filters to flush the fuel tanks and plumbing in composite aircraft before connecting the high-pressure electric pump to the system. Insure all plumbing, hoses, and installed fittings are free from debris. **DO NOT USE TEFLON TAPE ON FUEL FITTINGS**

2. Free-flow the boost pump to insure pick-up of fuel on initial run of boost pump.

Disconnect the fuel system plumbing before the engine driven fuel pump. Install a fuel hose into a suitable container. Upon initial start of the electric fuel pump, pump should pick up fuel within 5-15 seconds. If it does not, insure that the pump is wired correctly, the plumbing to the pump is correct, there is adequate fuel in the fuel system, and there are no air leaks on the suction side of the electric fuel pump. Flow ½ to 1 gallon of fuel into the container before shutting off the electric fuel pump and re-connecting the fuel system.

WARNING

Airflow Performance and Bendix/Precision fuel injection systems are non-returning systems. In the event that a tank is run dry in flight, an air lock will be formed on the outlet of the pumps. It is possible that the boost pump will not pick up fuel, as the boost pump cannot create enough air pressure to overcome the flow divider opening pressure, thus displacing the air and resume pumping fuel. It is not recommended to run a fuel tank dry in flight without adequate testing and proper documentation of the procedure for this operation.

- 3-9. If an electrical system is not installed on the aircraft, a manual wobble type boost pump may also be used. These pumps are generally used for starting, but do not afford the safety of an electric boost pump. Keep in mind that if the engine driven pump were to fail during take off, it would be highly unlikely that the engine could be restarted or caught before it quit by working the wobble pump to generate the necessary fuel pressure to run the engine in the time available. These pumps are generally heavier than the electric boost pumps.

INSTALLATION

ENGINE DRIVEN FUEL PUMP

- 3-10. Engines can be equipped with an engine driven fuel pump to supply the necessary fuel flow and pressure to the fuel controller. When the engine is equipped with magnetos for the ignition, this combination with an engine driven fuel pump, will allow the engine to operate with no electrical power on board. The minimum fuel pressure requirement for the system is dependent upon the engine output, system type, and installation. The engine driven fuel pump must be capable of supplying the required flow and pressure. Typically the pump output should be at least 1.5 times the engine requirements. If you are unsure of the pressure and flow requirements for your installation contact Airflow Performance to determine the correct pump output.
- 3-11. Lycoming engines usually use a high pressure diaphragm type engine driven fuel pump on their fuel injected models. This pump (LW-15473) generates 20-25 PSI while the engine is running. This is an acceptable pump to use with Airflow Performance fuel injection also. Some model engines use a vane type engine driven fuel pump. Romec or Lear are common names for these vane pumps. A common part number used is RG 17980 or RG 9080. This pump is usually required for use with turbo charged engines, due to the higher fuel pressure requirements. Make sure the pump relief pressure is set correctly for your application. Different engines may use other types of engine driven fuel pump. Consult the engine manufacture for pump compatibility.

FUEL PUMP COOLING

- 3-12. It is recommended to install a blast air shroud with associated ducting or duct blast air to the engine driven pump. This especially important where high ambient conditions or tight cowls are present.

INSTALLATION

FUEL PRESSURE GAUGE

- 3-13. Fuel pump output pressure is an important parameter to monitor. This can be picked up at the pump discharge port or fitting. The outlet fitting can be tapped to install a gauge fitting. The gauge fitting must have a restrictor installed. The restrictor should be .013-.020 inch dia. This will damp the pressure fluctuations to the gauge, and prevent dumping the fuel pressure if there is a gauge or gauge line failure. A number three or four hose is usually used to supply pressure to the gauge or pressure sender. In all cases the hose volume should be kept to a minimum. Make sure your gauge has sufficient range for your application. Selecting a gauge that has a 15 to 20 PSI higher range than the normal operating pressure is recommended. A 0-60 PSI gauge is a typical range for most installations.

FUEL LINE CONNECTION

- 3-14. Use fire sleeved hose for all plumbing on the inlet and outlet of the engine driven fuel pump. Typically the outlet side of the pump is plumbed with #6 (3/8) hose. The inlet hose to the fuel pump is sized based on the fuel system flow requirements. The metered fuel hose is connected to the fuel controller metered fuel outlet fitting and the flow divider or distribution block. This is typically #4 and should also be fire sleeved. Route all hoses away from heat sources and make the runs as short as possible. Use only aircraft quality fittings and aircraft grade hose recommended for fuel use. Teflon, fire sleeved hose is recommended for all hoses carrying fuel in the engine compartment.

MOUNTING THE FUEL CONTROLLER

- 3-15. The fuel controller can be mounted to the engine intake manifold flange at any attitude to facilitate the installation requirements. Airflow Performance has a variety of elbows and adapters to fit most applications. The fuel controller can be remote mounted to the engine. Keep in mind that the ducting or required piping must be able to with stand engine vacuum and intake pulsations. 5/16" studs are required to attach all fuel controllers to the manifold or adapters. Use self locking nuts with washers on the stud to secure the fuel controller to the manifold. If the fuel controller is remote mounted, make sure that the brackets and mounts supporting the fuel controller are strong enough to with stand "G" loads encountered in flight.


INSTALLATION

FUEL INLET CONFIGURATION


3-16. Your fuel controller has been configured for a specific application. There are three different fuel inlet configurations.

- 1.) Standard; the fuel inlet is in line with the air inlet and located near the air inlet.


Torque the AN-6 hose connection to 30-40 in-lbs.



Standard Fuel Inlet



90 Deg. Fuel Inlet



Side Mount Fuel Inlet


- 2.) 90 degree; the fuel inlet is a bulkhead 90 deg. type fitting which can be rotated and locked in any position, and is near the air inlet. The bulkhead nut is torqued to 150-160 in-lbs. Torque the hose connection 30-40-in-lbs.
- 3.) Side mount; the fuel inlet is located below the air inlet and is perpendicular to the air inlet. The side mount inlet will require the use of an angled hose fitting on the fuel inlet hose to permit clearance for the idle lever at wide open throttle. Most fuel inlet fittings are -6 AN (there are some high flow applications that are -8 AN, in standard configuration only).
- 4.) All inlet fittings incorporate a 74 micron non-removable inlet filter screen.

INSTALLATION


METERED FUEL OUTLET CONFIGURATION

3-17 There are three different types of fuel outlet.

- 1.) Standard; the outlet is a -4 AN fitting located at the center of the fuel controller regulator perpendicular to the throttle body bore.




STD. Fuel Outlet #4



90 deg. Fuel Outlet #4

- 2.) 90 degree; the fuel outlet is a -4 AN banjo type fitting. This fitting is positioned and locked during calibration, as the banjo bolt is part of the fuel regulator seat and is shimmed and torqued at the factory. It's position should have been noted when you filled out your option sheet when you ordered your system.



Straight Fuel Outlet #6


- 3.) -6 AN; this outlet is used for high fuel flow applications on engines running alcohol over 500 HP or engines developing over 800 HP on gasoline using a single fuel controller.

Torque the AN-4 hose connection to 25-35 in-lbs.

INSTALLATION

MANUAL MIXTURE CONTROL

- 3-18. If your fuel controller is fitted with the manual mixture control option you will find the manual mixture control installed opposite the idle lever. The mixture control can be clockwise or counter clockwise rotation. This designates the rotation of the valve to the full rich position. In the full rich position the "R" stamped on the mixture control stop lever is against the plastic stop. Rotating the control to the "ICO" position will lean the mixture. "ICO" is stamped on the opposite side of the mixture control stop lever.




Mixture control in Rich position




Mixture control in ICO position

When "ICO" is against the plastic stop, the fuel flow is shut off to the engine. There is approximately 1.0 to 3.0 PPH leakage in this position. The mixture control lever can be indexed to any position to facilitate the linkage hook up. The mixture control lever meshes with the clutch teeth on the mixture control stop lever. This gives 15 degree increments of lever adjustment. Make sure that the teeth on the two levers mesh correctly before tightening the lock nut. Use a 5/16" socket to loosen and tighten the 1/4-28 lock nut. . Make sure that the teeth on the two levers mesh correctly before tightening the lock nut. Torque the lock nut to 45-50 in.-lbs.



Correctly Meshed teeth




Incorrectly meshed teeth


NOTE: The manual mixture is not intended to be used as a fuel shut valve. If the fuel supply is near or above the level of the injector nozzles fuel will seep into the engine, or seep out the injector nozzle vents. A zero leak fuel shut off valve must be used on these installations.

INSTALLATION

THROTTLE LEVER




Correctly meshed Teeth



Incorrectly meshed teeth

3-19. The throttle lever can be installed on either side of the throttle shaft. It will typically be installed on the throttle stop lever side when the fuel controller is assembled. Like the mixture control lever, the throttle lever has clutch teeth that mesh with the throttle stop lever to give the throttle lever 15 degree increments of adjustment. Make sure that the teeth on the two levers mesh correctly before tightening the lock nut. Use a 3/8" socket to loosen and tighten the 5/16-24 lock nut. If you wish to install the lever on the other side of the throttle shaft, remove the lever from the throttle stop side and install on the opposite side of the throttle shaft. Mesh the lever with the teeth on the throttle shaft spacer and secure in place with a 5/16-24 lock nut. Purchase P/N 1090128 throttle shaft spacer, and install the spacer on the throttle stop lever side of the throttle shaft. Mesh the clutch teeth on the two parts and secure with a 5/16-24 lock nut. This is necessary to keep the throttle stop lever tight against the shoulder on the throttle shaft. . Make sure that the teeth on the two levers mesh correctly before tightening the lock nut. Torque the lock nut to 50-60 in.-lbs.

Throttle shaft
spacer
P/N 1090128



NOTE

A mechanical stop on the aircraft throttle and mixture control should be used to set wide-open throttle (WOT) and full rich (R) mixture setting. This will eliminate premature wear of the throttle and mixture stop levers. With the throttle in the WOT position it is acceptable to have up to 1/6 inch of clearance between the stop pin (roll pin) and the throttle stop lever. The mixture control should just hit the stop pin at each end of its travel.

INSTALLATION

CONTROLS

Refer to Appendix 'B' for control and linkage installation.

- 3-20. The control rods and levers used to operate the throttle and mixture control should be of rugged construction so that positive operation may be obtained. The levers are drilled to accept 3/16" bolts. Spherical bearing rod ends are recommended for attachment to the levers. The use of flimsy motorcycle type cables with return springs is not recommended. The system should be designed and built so that full movement of the fuel controller throttle and mixture levers is obtained, and the movement is in the proper direction. Insure that "G" loads encountered in flight will not change the position of the throttle or mixture control set by the pilot.

AIR INLET

Refer to Appendix 'C' for air inlet configurations.

- 3-21. Correct air flow into the fuel controller is necessary not only for optimum performance of the fuel controller, but to obtain peak performance from the engine as well. Cold ram air can be applied directly to the inlet of the throttle body with no adverse effects to the fuel metering capabilities of the fuel controller. It is best to have two sources of air to the fuel controller.
- 1.) Unfiltered cold ram air inlet.
 - 2.) Filtered alternate air inlet from inside the cowling. The filtered air provides protection to the engine during ground operations and if flying through rain, snow or ice. The ram air inlet provides maximum air density to the engine. This is especially important at high altitudes where the air density is low.
- 3-22. The air inlet on the cowling should have a smooth radiused entrance to the duct leading to the fuel controller. **DO NOT** connect a straight piece of tubing to the fuel controller entrance and have this piece of tubing protruding through the cowling to pick up the air. This type of sharp edge entrance does not flow air well and causes the fuel controller to enrichen the fuel air ratio. Be sure that where the air is picked up on the cowling is a high pressure area in flight. Consult the manufacture of the airframe or instrument the aircraft to record in flight air inlet pressure to confirm this. A 5 to 15 degree included angle duct is useful in providing smooth air into the fuel controller. The duct should be at least as big in diameter as the fuel controller inlet O.D. Scat tubing is an acceptable duct as long as the lengths are kept to a minimum. If 5 times the diameter of the tube will be used for length, consider using the next larger size scat tubing. Scat tubing does not flow air well due to its corrugated design. Smooth inner wall would be better for long runs.

INSTALLATION

Insure that the ducting cannot kink or collapse under use. Be a where of flexible tubing with an inner liner. Make sure the inner liner cannot collapse or peel back during installation.

- 3-23. For designs where the fuel controller inlet attaches to an air box, insure the box has adequate volume so the air slows sufficiently before turning and going into the fuel controller inlet. Install a radiused inlet in the box to smooth the air flow into the fuel controller. If you are unsure of the design of the box, contact Airflow Performance for approval. **NOTE: A poorly designed air box will adversely effect the operation of the fuel controller and the engine. Running an engine with this inlet configuration or without the air box attached, will result in a poor and extremely rich running engine. If the propeller blast flows across the top of the fuel controller inlet, disruption to the air flowing into the throttle body will result. There can even be a vacuum pulled on the air inlet causing the engine to surge and run erratically.**

FLOW DIVIDER


Refer to Appendix 'D' for Flow Divider installation.

- 3-24. If your installation requires the use of a flow divider, the location where the flow divider is mounted is dependent upon the installation. On Lycoming engines the common place to mount the flow divider is on the top of the engine. If the engine is down draft cooled, this will provide cooling air around the flow divider while the engine is operating. With the injector nozzles installed in the injector nozzle ports in the top of the cylinder heads, this also allows the installation of the shortest possible nozzle lines. It is a good idea to provide some type of vent or cowl flap to allow the heat to escape from the cowling when the engine is shut off. This will help to keep the fuel from boiling out of the flow divider and solve some of the hot start problems.
- 3-25. If your installation has up draft cooling or the injection nozzles are mounted in the primer ports, mount the flow divider under the engine. A common place on Lycoming engines for this installation is under the crankcase next to the starter, or mount a bracket off the oil sump attaching bolts.

NOTE: Always install the flow divider on the cool side of the engine.


INSTALLATION

- 3-26. The flow divider can be mounted in any position. Provide a sturdy mount to withstand engine vibration and "G" loads encountered in flight. of the flow divider to facilitate mounting. All Airflow Performance flow dividers have eight nozzle line ports. Choose any of the ports necessary to satisfy the nozzle line requirements and give convenient routing of the nozzle lines. Install the nozzle line fittings in the appropriate port and plug the other ports with the supplied 1/8" pipe plugs. A AN 816-4D (1/8 pipe to #4 straight) or AN 822-4D (1/8 pipe to #4 90 deg.) is typically installed in the port marked "IN".



10-24 UNC mounting holes. 4 locations

- 3-27. Connect the flow divider port marked "IN" to the metered fuel outlet on the fuel controller. Use a flexible No. 4 fire sleeved hose to connect the two components. Route the hose away from heat sources like the exhaust pipes. Clamp or tie off the hose securely to eliminate chaffing. Airflow Performance **does not** recommend the use of hard tubing for this connection.



"IN" port

DISTRIBUTION BLOCK

Refer to Appendix 'E' for Distribution Block Installation.

- 3-28. If your installation uses a distribution block, it must be mounted below the injector nozzles. For Lycoming engines, fabricate a bracket to mount the distribution block under the crankcase, or off the oil sump attaching bolts. For other engines, find a suitable place which keeps the block below the injector nozzles, and keeps the injector lines as short as possible. The distribution block should be mounted horizontal if possible, although satisfactory results have been obtained by mounting it in any position. Use a flexible No. 4 fire sleeved hose to connect the distribution block to the metered fuel out on the fuel controller. Route the hose away from heat sources like the exhaust system. Clamp or tie off the hose securely to eliminate chaffing. Airflow Performance **does not** recommend the use of hard tubing for this connection.

NOTE

Distribution block must be mounted below the injector nozzles and on the cold side of the engine for proper engine operation. If injector nozzles are not at the same level, improper idle operation will result.


INSTALLATION

FLOW METERS

- 3-29. You may wish to install a fuel flow meter in your installation. There are electronic models on the market available for aircraft use. These models typically use a turbine flow meter to measure the fuel flow. Install the turbine flow meter in the No. 4 metered fuel line. This is between the fuel controller and the flow divider or distribution block. Follow the manufacture's recommendation for installation of the flow meter. Install straight fittings in the inlet and outlet of the flow meter. "Full Flow" (curved tube) 90 or 45 degree hose fittings can be used on the inlet or outlet of the flow meter connection. Refer to Appendix D.

DO NOT CONNECT TURBINE TYPE FLOW METERS ON THE INLET OF THE ENGINE DRIVEN FUEL PUMP.

- 3-30. It is possible to use a pressure gauge, which measures nozzle backpressure to show fuel flow. The gauge must be calibrated for a specific number, and size of injector nozzles. If a flow divider is used, install a No. 2 or No. 3 fitting in the "GAGE" port. No restrictor is required in the gage fitting as the restrictor is machined into the flow divider body. The nozzle port directly below the "gage" port must be connected to an injector nozzle for the flow reading to be accurate. Run a No. 2 or No. 3 hose from the fitting on the flow divider to the pressure gauge. Keep hose volume to a minimum.



Fuel flow gauge connection.

Nozzle must be connected to this

- 3-31. If a distribution block is used in your installation, install a tee in one of the ports that has a nozzle line attached, or install the No. 2 or No. 3 fitting directly in a spare port on the block. The fitting must incorporate a .013" to .016" diameter restrictor in the fitting. Connect a No. 2 or No. 3 hose from the fitting to the fuel flow gauge. Keep hose volume to a minimum.
- 3-32. There are fuel flow gauges from certified engine installations, which may be applicable for your installation. These gauges are calibrated in GPH and have a usable range in the cruise and full throttle power area. If you want to calibrate a standard pressure gauge or use an existing fuel flow gauge, contact Airflow Performance for a gauge calibration sheet or conformation of the calibration of the fuel flow gauge you want to use.

NOTE:


Using a pressure gauge to indicate fuel flow is for reference purposes only. This method **should not** be used to determine fuel quantity on board the aircraft.

INSTALLATION

NATURALLY ASPIRATED INJECTOR NOZZLE

- 3-33. Naturally aspirated injector nozzles are identified by the gold anodized shield around the nozzle body. Each nozzle has a calibrated fuel restrictor that slips into the body of the nozzle. These are identified by machined bands on the body of the restrictor.

<u>BAND</u>	<u>SIZE</u>
None	.028
1	.022
2	.032
3	.015



NOTE
Airflow Performance injector nozzle restrictors are described above. Bendix / Precision restrictors are similar but their restrictor has one band on the restrictor body and are made from stainless steel. This is a .028 restrictor.

Do not mix restrictor sizes on the same engine.

To install the nozzle body; remove the restrictor and



apply a **small** amount of anti-seize compound to the pipe threads on the body. Install the nozzle with a clean 1/2" deep socket (a 1/4" drive, 6 point deep socket works well) to

tighten the nozzle. Make sure the hex is broached far enough into the socket so it will not damage the nozzle shield. Torque the nozzle body to 40 to 60 inch pounds. If the nozzle will be installed in any position other than vertical (discharge end down), tighten the nozzle to 40 inch pounds first then check for the position of the "A" stamped on one of the hex flats on the body of the nozzle. Continue to tighten the nozzle until the "A" points downward within a tolerance of one flat of the hex of the nozzle body. Do not exceed the maximum nozzle torque value when positioning the "A". This will position the air bleed hole in the body of the nozzle to face upward, and tend to keep fuel from dripping out the air bleed hole after engine shut down. Reinstall the fuel restrictor into the nozzle body before attaching the nozzle line.

TURBO INJECTOR NOZZLES


- 3-34 These nozzles are on engines using turbo or superchargers. They are also used on naturally aspirated engines where the position of the installed nozzle will be up side down (the discharge end of the nozzle is higher than the air bleed hole on the nozzle body). This is typical for Lycoming engines where the nozzles are installed in the primer ports. You may also choose to use these nozzles if the environment where the engine will be running is extremely dirty. These nozzles have a shroud, which uses two O-Rings to seal the air bleed section of the nozzle. There is a 3/16" diameter stainless steel tube brazed to the shroud for attachment of a 3/16" hose.



INSTALLATION

Each nozzle has a calibrated fuel restrictor that slips into the body of the nozzle. These are identified by machined bands on the body of the restrictor.

<u>BAND</u>	<u>SIZE</u>
None	.028
1	.022
2	.032
3	.015



NOTE

Airflow Performance injector nozzle restrictors are described above. Bendix / Precision restrictors are similar but their restrictor has one band on the restrictor body and are made from stainless steel. This is a .028 restrictor.

Do not mix restrictor sizes on the same engine. To install the nozzle body; remove the restrictor and apply a **small** amount of anti-seize compound to the pipe threads on the body. Install the nozzle body into the injector nozzle port on the engine. Use a clean 1/2" deep socket (a 1/4" drive, 6 point deep socket works well) to tighten the nozzle. Torque the nozzle body to 40 to 60 inch pounds. The B-

nut of the nozzle line will hold the spring and retainers in place. Be sure the nozzle restrictor is in place before connecting the nozzle line.



Refer to Appendix 'F' for nozzle Bleed Air Rail installation.

3-35. The shrouds of all the nozzles must be connected to in a way to vent the nozzle. A bleed air rail can be constructed to connect the nozzles on one side of the engine. This is typically built using 3/8" diameter stainless tubing for the rail between the nozzles, and 3/16" stainless tubing stubs silver soldered to the rail. Connect the stubs to the shroud tubes with short pieces of 3/16" hose. Clamp securely. If the installation uses a turbo or supercharger, the bleed air rails will be connected to the bleed air shuttle valve, or the turbo discharge. If the engine is naturally aspirated, connect hoses to the bleed air rail to vent them overboard or to the air box. Air will be drawn through the air bleed system when the engine is running so protect the system from picking up dirt. Naturally aspirated engines can also vent turbo nozzles by running individual 3/16" hoses from each nozzle. Run these hoses overboard or connect all the 3/16" hoses to one 3/8" hose and run it overboard. Do not connect more than six nozzles to one 3/8" hose. After engine shut down, some fuel may drip from the bleed air hoses.

INSTALLATION

Refer to Appendix 'G' for Bleed Air Shuttle Valve Installation.

BLEED AIR SHUTTLE VALVE

- 3-36. For turbo or supercharger installations where the fuel controller is installed on the inlet side of the compressor or blower, a bleed air shuttle valve is used to vent the injector nozzles. Install the shuttle valve using two Adel (cushion clamps) clamps. Install the valve with the body horizontal or with the screen up. Connect the ports marked "BLEED AIR" to the bleed air rail with No. 6 (3/8") hose. There are two ports for this connection. If only one hose is used, cap the other port with a AN-6 pressure cap. Connect the port marked "TURBO" to the turbo charger or blower outlet before an inter cooler, or the intake manifold. Use a No. 6 (3/8") hose for this connection.



STAINLESS STEEL INJECTION NOZZLE LINES

Refer to Appendix 'H' for Injector Nozzle Line installation.

- 3-37. If your system was sent to you without the nozzle lines, the injector nozzles and flow divider must be mounted on the engine to determine the correct nozzle line length. After the injector nozzles and flow divider or distribution block is installed, the injection nozzle lines can be fitted. Use wire or welding rod to simulate the routing of the lines. Keep the lines as short as possible routing them away from heat sources (like exhaust). Provide for places to clamp the lines. Airflow Performance recommends clamping the nozzle line every 6 to 8 inches. The lines do not have to be equal length, but keep the lengths within 12 to 15 inches of each other. After you determine the required lengths, contact Airflow Performance to order your nozzle lines. The lines are custom made to your specifications. On Lycoming engines, if the flow divider is mounted on top the engine, the lines are typically routed and clamped down the push rod tubes. If the flow divider or distribution block is mounted under the engine, the lines are typically routed and clamped to the intake pipes. Keep the lines away from the exhaust pipes. If a distribution block is used in the installation, not only the block must be mounted below the nozzles, but also route the nozzle lines below the injection nozzle until right at the nozzle then run the line up and into the nozzle.
- 3-38. When installing the nozzle lines, bend the lines to follow the required routing. The nozzle line material is annealed 1/8" diameter stainless steel tubing and can be easily bent by hand. If a tighter radius is required use a suitable tube bender. Minimum bend radius is 0.5". Provide at least 0.5" of straight tube from each end before starting a bend. Clamp the nozzle line tubing every 6 to 8 inches. Use 1/8" Adel clamps (cushion clamps) around the nozzle line

INSTALLATION

Do not place a piece of rubber hose around the nozzle tube then clamp around the hose. Clamp the Adel clamp directly to the nozzle line. It is acceptable to fire sleeve the nozzle line tubing but is generally not required. Make sure the nozzle restrictor is installed in the nozzle body and secure the nozzle line B-nut to the nozzle body. If using turbo nozzles install the nozzle shroud, O-ring, spring and spring retainers. The B-nut holds the shroud spring and retainers in place. Torque the B-nut to 20-30 inch pounds or seat the B-nut finger tight then tighten the B-nut an additional one-half flat.

Over torquing the B-nut will fail the fuel restrictor.

TYGON NOZZLE LINES

3-39. This type of nozzle line material is normally used on two stroke engines. A plumbing kit is supplied with this type of nozzle line material. Route all lines away from heat sources. Apply some oil to the fittings to help with the installation of the tubing. Use a cable tie around each hose connection. Tie and support the lines to keep them from rubbing or laying on engine components. Make sure the nozzle restrictor is installed in the nozzle body and secure the nozzle fitting B-nut to the nozzle body. If using turbo nozzles install the nozzle shroud, O-ring, spring and spring retainers. If a distribution block is used in the installation, not only the block must be mounted below the nozzles, but also route the nozzle lines below the injection nozzle until right at the nozzle then run the line up and into the nozzle. The nozzle fitting B-nut holds the shroud spring and retainers in place. Torque the B-nut to 20-30 inch pounds or seat the B-nut finger tight then tighten the B-nut an additional one-half flat.

Over torquing the B-nut will fail the fuel restrictor.

PURGE VALVE ASSEMBLY

Background

3-40. Modern light aircraft fuel injection systems are of the low pressure constant flow type. Fuel is metered and is delivered to air bled nozzles, which atomize and spray the fuel at each intake valve. Airflow Performance and Bendix fuel injection systems meter fuel to the engine based on engine air consumption. The fuel regulator in both these types of injection systems do not return any fuel to the tank, therefore only the fuel that is used by the engine flows through the fuel controller. Vapor in these types of metering systems causes the fuel regulator to operate erratically and poor engine performance will result. This is usually evident during hot restarts. Hot restart problems are a typical complaint of pilots operating fuel injected engines. After engine shut down heat in the cowling and engine tends to boil the fuel in the fuel control, fuel pump and related fuel metering components.


INSTALLATION

Some of the fuel expands in the nozzle lines and gets forced through the injection nozzles and into the engine. This leaves hot fuel and fuel vapor through out the complete fuel metering system, engine driven fuel pump included. During an attempted start under this condition usually results in the engine starting for a moment then quitting. The pilot is then faced with decision of how to proceed with the start procedure. Flooding the engine then cranking the engine until it starts is usually done. This procedure is dependent upon battery life, which sometimes expires before the engine starts. Engines, which use the high pressure diaphragm fuel pump, experience another problem, which influences the ease of restarting the engine. By their design the diaphragm fuel pump acts like an accumulator when the engine is shut down. This keeps fuel pressure on the fuel controller, and leakage in the idle cut off circuit of the fuel controller will allow the fuel to bleed off into the engine. This can cause run on in idle cut off and flooding of the engine initially after shut down.

PURGE VALVE INSTALLATION

Refer to Appendix 'I' for Purge Valve plumbing installation schematics.

- 3-41. The purge valve is a manually operated device. It can be actuated by cable or linkage. It should be installed as close to the flow divider or distribution block as possible. Refer to the attached schematic for correct hook up of the purge valve assembly. The purge valve body has three 10-24 UNC threaded holes to facilitate mounting it to a bracket. All ports on the purge valve body are 1/8 NPT. The port stamped "IN" is to be connected to the fuel controller's metered fuel outlet. The port stamped "OUT" is to be connected to the flow divider or distribution block inlet. Make this connection and or hose as short as possible. Use AN-4 fittings and hose for these two connections. The port stamped "RETURN" is to be run back to any tank. This connection can be AN-2 to AN-4. Running this return hose back to the gascolator or fuel pump will reduce the effectiveness of the purge valve as the hot fuel and vapor will only be circulated through the fuel system. It may be possible to return the fuel to a low point in the vent system. Test to insure that during purge the fuel will flow back into the tank and not out the overboard vent. Make sure the actuating control moves the purge valve lever fully to its stops, both "R" and "ICO". The actuating control should be placed in the cockpit where it will not inadvertently be moved during flight. A locking control is preferred.



PURGE VALVE ASSEMBLY MOUNTED
TO FLOW DIVIDER

INSTALLATION


Make sure the actuating control will keep the purge valve in the "R" position during all flight conditions and attitudes. Leak check all the connections and plumbing before starting engine. Lock wire all hard ware. Make sure to lock wire the stop screw.

WARNING

Failure to lock wire the stop screw holding the purge valve in the housing, will result in immediate engine stoppage if the screw backs out.

FLUSHING THE FUEL SYSTEM

- 3-42. **Before running the engine, flush out the fuel system.** Before connecting the high pressure electric boost pump it is best to flush out the fuel system plumbing and tanks. Install a low pressure automotive electric pump with a throw away fuel filter on the discharge end of the pump after the selector valve. Put a discharge hose on the end of the filter and return the hose to the fuel tank the fuel is being drawn from. Run the pump circulating the fuel from the tank until 7-10 gallons has passed through the system. Shake the plane to get debri and insure fuel has sloshed all over the inside of the tank. Repeat procedure for all fuel tanks, then connect the inline filter and high pressure boost pump. Disconnect the nozzle lines from the nozzles. Place all the nozzle lines in a container. With the mixture control on the fuel controller in the full rich position, turn on the boost pump. Open the throttle wide open. Fuel should be flowing through all the lines. Increase the fuel flow rate by blowing air into the fuel controller inlet. Use an air hose to accomplish this. Hold the air hose a foot away from the fuel controller air inlet and blow at the venturi. **DO NOT BLOW AT THE IMPACT TUBE.** Flow a quart or so of fuel through the system. Return the throttle to idle and turn off the boost pump. Reconnect the nozzle lines to the injectors. **Do not** over torque the nozzle line B-nuts.



CHECK LIST FOR FUEL SYSTEM INSTALLATION

1. Check airframe plumbing for secureness.
 - a. Tight connections.
 - b. No kinked or chaffing plumbing.
 - c. Check electrical wiring and electrical connector for boost pump.
 - d. Correct circuit breaker for boost pump.
 - e. Fuel system plumbing and wiring are free from interfering with full movement of all control surface controls.
2. Flush airframe fuel system plumbing before connecting high-pressure boost pump.
3. Free flow boost pump to insure pick-up of fuel on initial run of boost pump.
4. Check mounting hardware of fuel control, adapters, and brackets. Check lock nuts for correct engagement and torque. Check all screws requiring lock wire to be lock wired. Check Purge Valve stop screw for lock wire.
5. Check control cables for security to mounting brackets.
6. Check control cable rod ends for secured jam nuts and correct locking hardware on the actuating levers.
7. Check for correct engagement of the teeth on control levers.
8. Check operation of the manual mixture control. No binding. Check position to "Full Rich" and "ICO" with operation of the control in the cockpit.
9. Check operation of the throttle control. No binding. Check position to WOT to idle with operation of the control in the cockpit.
10. Check operation of the purge valve. No binding. Check position to "Full Rich" (run) and "ICO" with operation of the control in the cockpit.
11. Check security and clamping of the injector nozzle lines.
12. Check all hose connections in engine compartment. Fire sleeved hose, hoses tied off to prevent chaffing and away from exhaust system.
13. Injector nozzles installed with restrictors. Nozzle lines torqued at both ends.
14. Check air box installation. Check operation of alternate air valve if installed.
15. Pressure test fuel system. Purge valve in the ICO position.

SECTION FOUR

GENERAL OPERATING INFORMATION

GENERAL

- 4-1. Several phases of ground operation are adversely affected by fuel vaporization in the lines. Fuel vaporization may be experienced under extreme conditions of ambient and or nacelle temperatures. Starting, idle operation, and engine shut down procedures must be modified to obtain optimum results under these conditions.

STARTING

- 4-2. In cold weather , the engine compartment (nacelle) temperature drops off rapidly following engine shut down and the nozzle lines stay nearly full of fuel. Cold weather starting procedures are therefore simple with highly predictable results. However, in extremely hot weather, nacelle temperatures increase rapidly following engine shut down, and the fuel in the lines vaporizes and escapes out into the manifold. Hot weather starting procedures therefore depend considerably on how soon the next start is attempted. Within the first 20-30 minutes the manifold is nicely primed and the empty nozzle lines will fill before the engine dies. After a 20-30 minute wait, the vaporized fuel in the manifold will have nearly disappeared and some slight priming could be required to refill the nozzle lines and keep the engine running after first firing.

IDLING

- 4-3. During ground operation every precaution should be taken to keep nacelle temperatures from increasing to the extent that fuel will boil and vaporize in the lines. The following suggestions are aimed at minimizing this problem:
 - A. Keep nacelle temperatures as low as possible by:
 1. Avoiding excessive ground operation.
 2. Keep cooling air flow up by keeping engine RPM as high as possible.
 3. Place cowl flaps in the wide open position whenever practical.
 4. Upon restarting of a hot engine, operate the engine at elevated RPM'S (1200-1500 RPM for Lycoming's, different engines may require RPM'S suitable for the installation)for several minutes to reduce the residual heat in the engine compartment.
 5. Removal of heat from the cowling after engine shut down will aid in hot restarts.

GENERAL OPERATING PROCEDURES

- B. Keep fuel temperature as low as possible. Higher RPM's with the accompanying higher line pressure and flow will help to dissipate some of the heat within the lines.
 - 1. After restarting a hot engine, turn on the boost pump. This will pressurize the engine driven fuel pump to prevent vapor lock.
 - 2. The boost pump should be running during take-off, before letting down for landing approach, landing, and aerobatics. Under high ambient conditions it may be advisable to leave the boost pump running during taxiing to parking. Due to the low power output, fuel flow is minimal. This keeps the fuel on the suction side of the engine driven pump under pressure so it does not boil. Keeping the pump on during these conditions also provides back up incase of engine driven pump failure.

- C. Make an idle speed and mixture adjustment that is a compromise between the engine's requirement during the cool of the morning and the heat of the day.
 - 1. For Lycoming and similar engines, adjust the idle speed stop to provide 700-750 RPM or as high as practical. Other types of engines will require different idle speeds. The application the engine is used in will also determine the correct idle speed. A higher idle speed is sometimes objectionable due to its effect on landing and braking characteristics, both on roll-out and during taxiing.
 - 2. Adjust the idle mixture after the engine is to operating temperature. A slight RPM rise (10-40 RPM) may be observed when the mixture control is pulled slowly into idle cut-off.

SHUT DOWN

- 4-4. The idling procedure practiced just prior to engine shutdown has considerable bearing on the "cleanness" or smoothness with which the engine stops. If the idling procedures above are not followed and the fuel is vaporizing and emptying the lines, the engine may continue to idle rough for a few seconds. This is despite a 100% cut-off of the fuel supply by the mixture control.
 - A. Make sure the electric boost pump is turned off before attempting to shut the engine off.
 - B. Opening the throttle with the mixture control in the idle cut-off position will aid in a cleaner shut off.

GENERAL OPERATING PROCEDURES

OPERATION USING THE PURGE VALVE

- 4-5. Unless requested by the customer, all aircraft installations using a engine driven fuel pump incorporate a purge valve as part of the flow divider assembly. These are fuel injection systems using the FM-100, FM-200, FM-300 and FM-300A fuel controllers. The purge valve control is used to start and stop the engine for all starting and engine shut downs. Leave the manual mixture control in the “Full Rich” position. During engine shut down the purge valve is put into the off or ICO position. This will allow the metered fuel to the engine to be shut off at the flow divider and be diverted back to the tank. This positively shuts the fuel off to the engine and allows the fuel pressure to dump in the system. The fuel controller mixture control is left in the full rich position. During a hot restart, the mixture control is left in the full rich position. Leaving the purge valve in the off position, open the throttle at least ½ open and turn the boost pump on. Fuel will then circulate through the engine driven pump, fuel controller, to the flow divider and back to the tank. This will flush the hot fuel and vapor from the system and cool the fuel injection components. A short prime may or may not be necessary for a hot start. Return the throttle to off idle, turn on the ignition and crank the engine. When it starts return the purge valve control to the run position. The engine will continue to run after it starts since the system is completely purged of vapor and the engine driven pump and fuel controller are filled with cool fuel. On a hot start it may be necessary to keep the boost pump running after the engine starts.

See Page 48 and 49 for Purge Valve Operating Procedures.

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION FIVE

FIELD ADJUSTMENTS

STARTING PROCEDURE FOR INSTALLATIONS WITHOUT A PURGE VALVE

5-1. The following starting procedure has proven successful in installations using an engine driven fuel pump and an electric boost pump and no purge valve.

A. Cold Starts

1. Mixture control in the IDLE CUT-OFF position.
2. Set throttle to 1/8 open position.
3. Master switch -ON-.
4. Boost pump switch -ON-.
5. Move the mixture control to FULL-RICH until the fuel flow indicator reads 4 to 6 GPH then immediately return the mixture control to the cut-off position.
6. Boost pump switch -OFF-.

NOTE

On installations where a fuel flow indicator is not used, allow 4 to 5 seconds in place of reading 4 to 6 GPH on the gauge, or turn the boost pump on until an indication of fuel pressure is observed on the inlet fuel pressure gauge (5 to 10 PSI) then turn the pump off.

REMEMBER

Fuel will flow into the engine as long as the boost pump is left on.

7. Crank engine. When engine fires, put mixture to FULL RICH and throttle to idle.

B. Warm Starts

1. Use the same procedure as for cold starts except the boost may be left "off:" and step 4, 5, AND 6 eliminated. DO NOT PRIME.

FIELD ADJUSTMENTS

C. Shutting Engine Off

1. Bring engine to idle.
2. Turn off boost pump.
3. Put mixture control to IDLE CUT-OFF position.
4. When engine quits, turn off ignition.

NOTE

The mixture control in the cut-off position is only intended to "Cut-Off" fuel to the engine. It is not intended as a fuel shut off valve. From 1.0 to 3.0 PPH leakage will flow through the fuel controller with the boost pump running and the mixture control in "ICO".

D. Starting Flooded Engine

1. Open throttle wide open.
2. Leave boost pump -OFF-.
3. Put mixture control in IDLE CUT-OFF.
4. Crank engine. When engine starts, bring throttle toward idle and slowly move mixture to FULL RICH as engine "cleans out".

5-2. The following starting procedure has proven successful in **installations using only electric fuel pumps**. Typically with these installations, the mixture control can be left in the FULL RICH position during starting and shut off procedures.

A. Cold Starts

1. Mixture control in the FULL RICH position.
2. Set throttle to 1/8 open position.
3. Master switch -ON-.
4. Fuel pump switch -ON-.
5. When the fuel flow indicator reads 4 to 6 GPH turn the fuel pump switch -OFF-.

FIELD ADJUSTMENTS

NOTE

On installations where a fuel flow indicator is not used, allow 4 to 5 seconds in place of reading 4 to 6 GPH on the gauge, or turn the fuel pump on until an indication of fuel pressure is observed on the inlet fuel pressure gauge (5 to 10 PSI) then turn the pump -OFF-.

REMEMBER

If the fuel pump is left on when the engine is not running, the engine will flood and fill with fuel.

6. Crank engine. When engine starts, turn the fuel pump -ON- and bring the throttle to idle.
- B. Warm Starts
1. Use the same procedure as for cold starts except eliminate step 4 and 5. DO NOT PRIME.
- C. Shutting Engine Off
1. Bring engine to idle.
 2. Turn off fuel pump.
 3. When engine quits, turn off ignition.
- D. Starting Flooded Engine
1. Open throttle wide open.
 2. Leave fuel pump -OFF-.
 3. Crank engine. When the engine starts, bring throttle toward idle and when the engine starts to run "clean", turn -ON- the fuel pump.

FIELD ADJUSTMENTS

IDLE SPEED AND MIXTURE ADJUSTMENT

- 5-3. The following instructions deal with setting the idle mixture and speed on the engine. A preliminary idle adjustment has been set at the factory. This should be sufficient to get the engine started and running.

WARNING


The following procedure is performed with the engine running. The aircraft should be in an area that is safe for running and securely tied down. Use extreme caution while working around running engines. Be aware of your position relative to the propeller. If you are unsure of your ability to work around running aircraft engines, don't attempt this procedure, find someone who is qualified to perform it for you. Have a qualified person in the cockpit during the adjustment.

DO NOT attempt this adjustment alone.

DO NOT leave the cockpit or engine running unattended.

1. Warm the engine to operating temperature.
2. Make sure operating temperatures are not exceeded while running with the engine uncowled as cooling air over the engine may be decreased during ground operation.
3. Check magnetos in accordance with the instructions furnished in the aircraft or engine operational manual. If the "mag-drop" is normal, proceed with the idle adjustment.
4. Set the idle speed with the speed stop bolt (on the throttle stop lever). Set the idle speed to the engine manufactures specification, or set the idle speed as high as practical. Lycoming engines are set to idle approximately 700 to 750 RPM. If the RPM changes appreciably after making an idle mixture adjustment during the succeeding steps, re-adjust the idle speed to the desired RPM.
5. The optimum idle setting is one that is rich enough to provide satisfactory acceleration under all conditions and lean enough to prevent spark plug fouling or rough operation.

FIELD ADJUSTMENTS



6. The actual idle mixture adjustment is made by lengthening (rich) or shortening (lean) the linkage between the throttle stop lever and the idle lever. When it is turned out of its block, the link becomes longer and a richer idle mixture is provided. When it is turned into its block the linkage is shortened and a leaner idle mixture is provided. There is a left and right hand jam nut to lock the linkage. Use two 3/8" wrenches to make the adjustments. The left hand thread is on the throttle stop lever end. Loosen one jam nut but leave the other jam nut just snug. This will provide a little drag on the adjustment and make the adjustment easier and more accurate. Tighten both jam nuts after correct idle mixture is achieved.

NOTE

This adjustment will not effect the wide open throttle mixture.

7. Finding the optimal mixture is usually found by leaning the idle mixture link one flat at a time until the engine will not take the throttle while making a brisk advance of the throttle from idle. When this point is found, richen the mixture one or two flats.

FIELD ADJUSTMENTS

8. Another method for finding correct idle mixture is to check RPM rise. When the idle speed has been stabilized, move the cockpit mixture control with a smooth, steady pull, into the IDLE CUT-OFF position and observe the tachometer for any change during the leaning out process. Caution must be exercised to return the mixture control to the FULL RICH position before the RPM can drop to a point where the engine cuts out. An increase in RPM while leaning out indicates the idle mixture is on the rich side of best power. An immediate decrease in RPM (if not preceded by a momentary increase) indicates that the idle mixture is on the lean side of best power. A rise of 10-40 RPM is typical.
If a manifold pressure gauge is a cockpit instrument, it can be used to set optimal idle mixture. Lean or richen the idle mixture until the lowest manifold pressure is obtained at idle speed. **Typical idle mixture for Lycomings is .3" to .5" MAP richer than the lowest reading.** This will also give the best idle mixture.
9. Each time an adjustment is made, clear the engine by running it up to 1/4 to 1/2 throttle then back to idle before making a mixture check.
10. Changing the idle speed will affect the idle mixture. Work between the two adjustments to get the best operation.
11. Make the final idle speed adjustment to obtain the desired idling RPM with the throttle closed.
12. If the setting does not remain stable, check the idle linkage; any looseness in this linkage will cause erratic idling. In all cases, allowances should be made for the effect of weather conditions upon idling adjustments. The relationship of the aircraft to the direction of the prevailing wind will have an effect on the propeller load and its RPM; hence it is advisable to make the idle setting with the aircraft cross-wind.
13. Idle speed and mixture adjustments made according to this method should require very little further attention except for extreme variations in temperature and altitude.
14. Erratic idle may be encountered under prolonged idle or high under cowl temperatures. Running the engine up briefly will clear the hot fuel from the nozzle lines.

FULL THROTTLE MIXTURE ADJUSTMENT


- 5-4. The following instructions deal with the full throttle mixture. An EGT (exhaust gas temperature) gauge is highly advisable to determine the correct mixture strength. The fuel air ratio in your fuel controller has been set at the factory for flow limits established by the engine manufacture. While these limits generally satisfy the engine requirements, modifications to the engine may require a slightly different fuel air ratio.

FIELD ADJUSTMENTS


WARNING

The following procedure will require that the engine will be operated under full power. The aircraft must be in an area suitable for full throttle run-up. The aircraft must be chocked and tied down securely. **DO NOT** rely on the aircraft brakes to hold the aircraft during this test. Observe engine operating temperatures and operation during full throttle. If any temperatures or parameters are exceeded or engine operation is not normal or erratic, immediately discontinue full throttle operation.

1. Bring the engine up to operating temperature.
2. Put the mixture control to the FULL RICH position.
3. Advance the throttle to wide open.
4. Observe the RPM and EGT. These parameters must be within the engine manufactures specifications. Typical full throttle EGT for Lycoming engines is 1300 to 1375 degrees Fahrenheit. On most 4-stroke engines, correct full rich mixture is indicated by an increase of 25 to 50 RPM when the mixture is manually leaned while at full throttle. This is with a fixed pitch prop. On engines with constant speed props, correct mixture can be determined by EGT change from full rich to peak EGT. To determine mixture using this method power must be set 22-24" MAP **at no higher than 3500 ft. MSL**. Record peak EGT on one cylinder then record full rich EGT on the same cylinder. The difference in EGT between peak and full rich should be 185 to 225 degrees F.
5. If the full rich full throttle mixture is not correct, it can be adjusted by changing the main jet located inside the fuel controller.
6. The main jet is located under the inlet filter fitting, the 90 degree inlet filter fitting, or for those fuel controllers with side mount inlet filter fitting it is located under the blue plug (you must remove the side mount inlet filter also).



FIELD ADJUSTMENTS



7. Main jets are precision flowed parts, and can be purchased from Airflow Performance. Jets are sized like number drills (a #48 is leaner than a #46) and are also available in half sizes. Use extreme caution when removing or installation the main jet. Be careful not to chip or allow the screw driver to slip on the jet. Do not over tighten the jet when reinstalling. Apply some oil to the O-rings when reinstalling the fittings.
8. Re-lockwire the side mount inlet filter screws if removed.

OPERATING INSTRUCTIONS FOR USING THE PURGE VALVE

- 5-5. The following instructions are recommended procedures for operating engines with engine driven fuel pumps.

COLD STARTS

- Purge valve off (“ICO” position).
- Mixture control "FULL RICH".
- Throttle open ½ or more.
- Turn on boost pump. Run for 30-45 seconds
- Put purge valve to run (“R” position), count to five then return purge valve to off position. Actual prime time may be different from installation to installation. If the engine tends to flood, reduce the throttle to off idle then prime the engine.
- Reduce throttle to 1/8 or off idle.
- Leave the Mixture control in the full rich position.
- With mags "HOT", crank engine, when engine fires, put the purge valve in the run position and the throttle to idle. After the engine stabilizes idle, the boost pump can be shut off.

FIELD ADJUSTMENTS

ENGINE SHUT DOWN

- Bring engine to idle speed.
- Leave mixture control "FULL RICH".
- Turn boost pump off.
- Put purge valve control to "OFF" position.
- Turn off the ignition.

HOT STARTS

- Mixture control "FULL RICH".
- Throttle ½ to wide open.
- Purge valve "OFF" position.
- Turn on boost pump and let run 30 to 45 seconds. This will purge the hot fuel and vapor from the system, and will cool and fill the fuel system components with cool fuel.
- Leave the the boost pump on.
- Set Throttle to 1/8 open.
- Give engine a short prime by putting the purge valve to “run” then back to “off”. The amount of prime required may vary from installation to installation.
- Leave Mixture control "Full Rich".
- With mags "HOT", crank engine, when engine fires, return throttle to idle and purge valve to “Run”.
- Leave the boost pump on during hot, low power, operation.

Another method for starting the engine when hot is to leave the mixture “rich” after purging the system. With the purge valve in the ICO position and the throttle at idle, crank the engine while slowly moving the purge valve to the Rich position. The engine will start during this movement to the Rich position.

THIS PAGE INTENTIONALLY LEFT BLANK

TROUBLESHOOTING

- 6-1. Effective troubleshooting is an art that separates the professionals from the amateurs. To be able to pinpoint the problem or problems causing the malfunction is effective troubleshooting. Removing and replacing components on a trial and error basis is "shotgun" troubleshooting in its worst form. Shotgunning is expensive, time consuming, and nothing can be learned from it. To be effective, troubleshooting must be an analysis of the problem, its probable causes, and the necessary actions to correct the problem, and if possible, prevent it from happening in the future.

- 6-2. There are several points to keep in mind in developing an effective troubleshooting procedure for engines, their systems, and components. A complete understanding of basic engine principles and theory of operation is necessary to determine the path to follow to solve the problem. A suggested method, which, with minor changes, can be adapted to almost any engine, consists of five basic steps. These are:
 1. STUDYING THE SYMPTOMS
 2. ISOLATING THE SYSTEM EFFECTED
 3. DETERMINING THE PROBABLE CAUSES
 4. CHECKING AND REPAIRING
 5. TESTING AND DOCUMENTING THE RESULTS

Possible causes are listed on the following pages in the troubleshooting charts, along with methods for determining correct operation of the individual components in the text following with out resorting to "changing the part and see if that fixes the problem".

The fuel controller in it self, is a fairly simple device. There are many engine symptoms that may mimic a fuel injection problem, but on understanding the operation of the fuel control system these symptoms can be isolated. An intermittent problem is usually not caused by the fuel controller it self do to the simple nature of its operation.

TROUBLESHOOTING CHART

PROBLEM	PROBABLE CAUSE	REMEDY
Hard starting	Technique	Refer to sections 5-1 and 5-2 also aircraft and engine manufacturers recommended starting procedure.
	Flooded	Refer to sections 5-1 and 5-2.
	Throttle valve open to far.	Open throttle to 1/8 or less. Amount may vary for given application
	Insufficient prime (usually accompanied by a backfire).	Increase amount of priming.
	Slow cranking speed Ignition timing Weak spark	Inspect starter motor, battery, associated wiring and components. Ignition may also be effected by slow cranking speed.
Rough idle	Mixture too rich or too lean.	Confirm with manual mixture control. Adjust idle mixture as per section 5-3.
	Restricted nozzle High take-off fuel flow may also be indicated on a fuel flow gauge, which measures nozzle back pressure.	Flow test and clean nozzles per instruction in section 6-7 and 6-8.
	Sheared nozzle restrictor. Caused by over torquing nozzle line B-nut.	Remove failed restrictor from nozzle body. Replace with correct restrictor size and torque nozzle line B-nut to 20-30 in-lbs.
	Restricted flow divider port. (If flow divider is used)	Flow test and clean per instruction in section 6-9
	Slight air leak into induction system through manifold drain if used.	Confirm by temporarily plugging drain valve. Repair or replace valve as necessary.
	Slight air leak into induction system through loose intake pipes or damaged seals or gaskets.	Repair as necessary.
	Incorrect ignition timing	Set to engine manufacturer's specifications.
	Incorrect valve lash Sticking valves	Set to engine manufacturer's specifications.
	Stuck flow divider valve.	Insure flow divider spool valve moves freely. See 6-10.

TROUBLESHOOTING CHART (Continued)

PROBLEM	PROBABLE CAUSE	REMEDY
Rough idle (Continued)	Injector nozzle lines draining. For installations using distribution blocks.	Mount distribution block below nozzles. Route nozzle lines below nozzles until connection to nozzle is made.
	Air in fuel supply.	Test per instructions in section 6-3.
	Fuel vaporizing in nozzle lines, distribution block, or flow divider. Encountered under high ambient temperature conditions, or following prolong operation at low RPM's.	Refer to section 4-3.
	Baffling hitting cowling.	Make sure only rubber seal strips contact cowl.
Unable to lean idle mixture.	Hung fuel controller regulator. (trash in regulator)	Test per instructions in section 6-4.
	Idle valve has excessive clearance	Test per instructions in section 6-5.
	Clogged air bleeds on injector nozzles. Restricted bleed air rail or stuck bleed air shuttle valve (turbo engines).	Inspect and repair as necessary.
Off idle stumble	Idle mixture to lean.	Reset idle mixture. Refer to section 5-3.
	Intake manifold leak.	Inspect and repair as necessary.
	Incorrect ignition timing.	Reset to engine manufacture's specifications.
	Air in fuel supply.	Test per instructions in section 6-3.
	Fuel vaporizing in nozzle lines, distribution block, or flow divider. Encountered under high ambient temperature conditions, or following prolong operation at low RPM's.	Refer to section 4-3.
Engine hangs on first acceleration of the day.	Air in fuel controller.	A brief hesitation is common on first start-up. This symptom should clear after the engine is run up.

TROUBLESHOOTING CHART (Continued)

PROBLEM	PROBABLE CAUSE	REMEDY
Engine hangs on first acceleration of the day. (Continued)	Oil or fuel contamination in the air section of the fuel controller.	Normally this is an indication of a turbo-charger seal leak. Return fuel controller for repair.
Engine hangs or is slow to transition off idle	Ignition	Make sure ignition is operating correctly and is timed to the engine manufacture's specs.
	Propeller	Incorrectly pitched prop Low pitch stop incorrectly set.
Engine is slow to transition mid-range to full throttle power and runs rich	Propeller	Low pitch stop incorrectly set. Possible prop governor problem.
	Turbo system	Differential pressure controller, waste gate, or waste gate control malfunction.
Low take-off fuel flow. Lean engine operation.	Insufficient inlet fuel pressure	Confirm fuel pressure requirement for maximum HP.
	Plugged inlet filter fitting or flow divider filter.	Remove filter fitting, clean and reinstall. Remove flow divider cover and diaphragm/valve assy. Back flush screen. See 6-10
	Restricted fuel supply to fuel pump. Problem can sometimes be confirmed by turning on boost pump.	Test for restriction in aircraft fuel system plumbing, filters, valves, fittings, etc. Eliminate 90 degree fittings on the inlet side of pumps.
	Stuck flow divider valve.	Flow divider valve must move freely. DO NOT SAND OR REMOVE METAL FROM VALVE. <u>Lightly</u> polish with 1200 wet/dry or Crocus cloth if necessary. Check for contamination and correct.
	Induction system air leaks	Inspect and repair as necessary. Pressure test induction system. (Disconnect M.A.P. gauge before performing pressure test.)

TROUBLESHOOTING CHART (Continued)

PROBLEM	PROBABLE CAUSE	REMEDY
Lean operation	Air in fuel supply.	Test per instructions in section 6-3.
Low take-off fuel flow. Lean engine. (Continued)	Incorrect full throttle fuel/air ratio. (Accompanied by high EGT)	Refer to section 5-4.
	Leaks or restrictions at nozzle lines.	Check nozzle lines for loose fittings or B-nuts. Check for kinks in line and cracks at braze joints.
	Incorrect gauge reading. (Accompanied by normal EGT)	Insure gauge is calibrated for correct number and size of nozzles. (When using nozzle back pressure gauge for flow meter)
Insure correct K factor is installed into turbine type flow meter computer.		
High take-off fuel flow. Rich engine.	Restricted nozzle. Accompanied by high fuel flow reading if pressure gauge type fuel flow gauge is used.	Remove and clean nozzles as per instructions in section 6-7 and 6-8.
	Incorrect full throttle fuel/air ratio. (Accompanied by low EGT)	Refer to section 5-4.
	Incorrect gauge reading. (Accompanied by normal EGT)	Insure gauge is calibrated for correct number and size of nozzles. (When using nozzle back pressure gauge for flow meter)
		Insure correct K factor is installed into turbine type flow meter computer.
	Restricted air inlet.	Check for clogged air filter, collapsed or obstructed duct.
	Heated air inlet.	Pulling inlet air from inside the cowl area may result in rich operation and low power output due to low air density (heated air).
No inlet or incorrect approach on fuel controller air inlet.	Refer to section 3-21 and 3-22.	

TROUBLESHOOTING CHART (Continued)

PROBLEM	PROBABLE CAUSE	REMEDY
Engine will not accelerate past a given RPM.	Restricted nozzle if accompanied by high fuel flow reading on pressure type fuel flow gauge.	Remove and clean injector nozzles as per instructions in section 6-7 and 6-8.
	Improper internal engine timing or ignition problem.	Correct timing problem.
	Restricted exhaust system.	Refer to engine manufacture for corrective action.
	Restricted intake manifold.	Insure correct gaskets are used and are installed correctly on intake manifold.
	Incorrectly pitched propeller.	Insure correct pitched prop.
	Throttle control not rigged properly.	Insure throttle on fuel controller opens to wide open stop when throttle control is at full throttle.
Poor cut-off.	Improper rigging of mixture control.	Adjust. ICO side of mixture control stop lever must be against plastic stop.
	Idle mixture set to rich.	Adjust idle mixture per instructions in section 5-3.
	Excessive clearance on mixture control valve. <u>Note:</u> 1.0 to 3.0 PPH leakage is normal for the mixture control in the ICO position. The purpose of the mixture valve is to shut the engine off in the ICO position, not to replace the aircraft fuel shut off valve.	Return fuel controller to for repair. Test for mixture control leakage as outlined in section 6-6.
	Vapor in nozzle lines.	Refer to section 4-3.
Inlet fuel pressure gauge fluctuations.	Restriction on inlet side of fuel pump.	Check for clogged filters, restricted fittings or hoses, incorrect sized fuel supply lines.
	Fuel boiling on inlet side of pump (vapor locking pump). This is common when using a vane type engine driven fuel pump with high under cowl temperatures and low RPM.	Turn on boost pump before reducing power. Leave boost pump on during idle operation.

TROUBLESHOOTING CHART (Continued)

PROBLEM	PROBABLE CAUSE	REMEDY
Inlet fuel pressure gauge fluctuations. (Continued)	Air in fuel system.	Test per instructions in section 6-3.
	No bleed or to large restrictor in gauge line.	Refer to section 3-13.
	Air in gauge line.	Purge air from line.
Engine runs rich and rough until oil temperature reaches 130-140 degrees.	The fuel injection system is not effected by oil temperature. Valve train problem, excessive oil pressure, malfunctioning hydraulic lifters, spalled lifters, incorrect valve lash.	Contact engine manufacture.
Engine loses power and fuel flow after running at maximum out put for a few minutes. After a subsequent restart full power and RPM is obtained, then after a few minutes of operation the engine loses power.	Since fuel flow is controlled by engine airflow consumption, a loss in power and fuel flow while running at WOT is indicative of an ignition problem. A possibility is changing ignition timing or bad spark plugs.	Test ignition system and spark plugs. Check valve guides for sticking valves.

TROUBLESHOOTING

TESTING FOR AIR IN THE FUEL SYSTEM

WARNING

The following procedure is performed with the engine running. The aircraft should be in an area that is safe for running and securely tied down. Use extreme caution while working around running engines. Be aware of your position relative to the propeller. If you are unsure of your ability to work around running aircraft engines, don't attempt this procedure, find someone who is qualified to perform it for you. Have a qualified person in the cockpit during the adjustment.

DO NOT attempt this adjustment alone.

DO NOT leave the cockpit or engine running unattended.

- 6-3. The following procedure can be used to determine if air is getting into the fuel supply. After determining if air bubbles are in the fuel, work backward through the fuel system, removing components one at a time until the cause is found.
1. Connect a length of clear piece of Teflon tube between the fuel controller and the flow divider or distribution block. A 2 to 3 inch piece is all that is required to be clamped between two AN style fittings.
 2. Run the engine and watch for air bubbles. Bubbles may initially be observed at start up and at idle. Run the engine up to a mid power setting. If bubbles are observed after 30 seconds or so then shut the engine down and proceed with step 3. It is common to see some air in the metered fuel lines or nozzle lines after start up and during prolonged idle. This air should clear out when the engine is run up to full power.

TROUBLESHOOTING

3. If air is observed during part and full throttle operation, proceed by disconnecting the fuel supply hose from the fuel controller. Use a valve and pressure gauge to put back pressure on the system. Set the valve to give 15 to 20 PSI with the boost pump running. Flow the fuel into a suitable container and observe the fuel stream for air. Continue testing back through the fuel system, removing one component at a time until the air source is found. Primary sources are:
 - A. Heat being transferred to flow divider or distribution block.
 - B. Fuel lines routed too close to exhaust system.
 - C. Heat being transferred to fuel hoses under low flow conditions (idle power).
 - D. Deteriorated main fuel (engine driven) fuel pump seals.
 - E. Airframe boost pump shaft seal leakage.
 - F. Damaged cones and flares on fuel line fittings.
 - G. Flow restricting component on inlet side of fuel pump.
 - H. Restricted fuel tank vent.

NOTE


Fuel fittings and lines can leak air and not fuel if the line or hose is on the suction side of the fuel pump. If having the boost pump on improves operation, then a leaky fitting or hose is possible between the boost pump and the selector valve or boost pump and the engine driven pump. You will typically see fuel leakage when this area is pressurized.

TESTING FOR CORRECT OPERATION OF THE FUEL CONTROLLER

- 6-4. The following procedure tests the operation of the fuel controller regulator. It is not intended to be used to determine if the fuel controller is in calibration.
 - A. Disconnect the hose that attaches to the flow divider or distribution block (metered fuel hose). Leave the hose attached to the fuel controller.
 - B. Place the hose in a suitable container.
 - C. Turn the boost pump on and put the mixture control Full Rich. Open the throttle wide open.
 - D. Fuel should be flowing out the metered fuel hose.

TROUBLESHOOTING

- E. Use an air hose to blow air at the venturi. This will simulate air flowing into the engine. Hold the air nozzle a foot or so away from the fuel controller air inlet. DO NOT BLOW DIRECTLY AT THE IMPACT TUBE.



F.

Blow air at
the boost
venturi

Impact
tube

Observe the metered fuel flow. When blowing air at the venturi the fuel flow should increase immediately to a high rate. When the air is stopped the flow rate should immediately slow to a low rate. Do this procedure three or four times to make sure the fuel controller tracks the air flow inputs.

- G. With the boost pump still running, and no air flow, return the throttle to idle. The metered fuel flow should slow to a lower rate (idle fuel flow).
- H. Observe the impact tube during the test while the boost pump is running. There should be no fuel dripping or flowing from this port.

If the fuel controller does not perform as described in the above procedure, there is a malfunction or contamination in the fuel controller regulator. Continue with the following procedure:

TROUBLESHOOTING


- I. With the throttle wide open, mixture full rich, boost pump on, and air blowing at the venturi, turn the boost pump off and on several times. Continue to blow air at the venturi while turning the pump off and on. This will cause the regulator to travel to its maximum limit and will tend to flush any contamination from between the regulator ball and seat.
- J. Re test as described in steps "C" through "G".

If the fuel controller does not perform as described in the above procedure, there is a malfunction or contamination in the fuel controller regulator. Return the fuel controller for repair.

IDLE VALVE LEAKAGE TEST

- 6-5. The following procedure tests for excessive idle valve leakage. The fuel controller must pass the test in section 6-4. before proceeding with this test.
 - A. Disconnect the hose that attaches to the flow divider or distribution block (metered fuel hose). Leave the hose attached to the fuel controller.
 - B. Place the hose in a suitable container.
 - C. Turn the boost pump on and put the mixture control Full Rich. Open the throttle wide open.
 - D. Observe the fuel flowing from the metered fuel hose, now close the throttle to idle. The fuel flow should decrease to a lower level.
 - E. Disconnect the idle linkage at the idle valve lever by removing the 10-24 cap screw and lock nut. Do not loosen the 8-32 clevis lock nut on the idle lever it self. Slowly rotate the idle valve lever counter clockwise. The fuel flow should continue to slow to a fast drip (10 to 20 cc's per minute).

TROUBLESHOOTING



8-32 idle lever clevis lock nut

F.

If the fuel controller responds as explained in part "D" and "E", the fuel controller is operating correctly. Reconnect the idle linkage to the idle valve lever with the 10-24 cap screw and lock nut. Make sure the idle valve rotates clockwise when the throttle is opened.

If the fuel controller does not perform as described in the above procedure, there is excessive leakage around the idle valve or contamination in the fuel controller regulator. Return the fuel controller for repair.

MANUAL MIXTURE CONTROL LEAKAGE TEST

- 6-6. The following procedure will test for correct operation of the manual mixture control. The Manual Mixture Control on FM fuel controllers in the idle cutoff position will only reduce the fuel flow sufficiently to stop the engine. It is not a zero leak valve. It is not intended as a fuel shut off valve. The fuel controller must pass the tests described in section 6-4 before proceeding with this test.
- A. Disconnect the hose that attaches to the flow divider or distribution block (metered fuel hose). Leave the hose attached to the fuel controller.
 - B. Place the hose in a suitable container.
 - C. Turn the boost pump on and put the mixture control Full Rich. Open the throttle wide open.
 - D. Observe the fuel flowing from the metered fuel hose, now close the throttle to idle. The fuel flow should decrease to a lower level.

TROUBLESHOOTING

- E. Put the manual mixture control into Idle Cutoff (ICO).
- F. The fuel flow should decrease to a slow drip (1.0 to 3.0 PPH). Lightly tapping on the throttle body with the plastic handle of a screw driver may decrease the dripping rate. This is normal as the regulator ball is seating more firmly into the seat.

If the fuel controller does not perform as described in the above procedure, there is excessive leakage around the manual mixture control, contamination in the fuel controller regulator, or excessive leakage between the regulator ball and seat. Return the fuel controller for repair.

TESTING INJECTOR NOZZLES

NOTE

The following procedure is intended as a troubleshooting aid only, and should not be construed as a calibration check of the nozzle assembly. If a question exists regarding the serviceability of a given nozzle, the nozzle assembly should be returned for repair.


- 6-7. The following procedure tests for nozzle spray pattern and flow division between nozzle assemblies. If a flow divider is installed in the system it must be tested per the instructions in section 6-9 before proceeding with this test. If a distribution block is used in the installation make sure that all the nozzle lines route above the block and that all the nozzles are at the highest point and at the same level. Make sure that the same size restrictor is in each nozzle assembly.
 - A. Remove each nozzle from the engine and reattach the injector nozzle to the nozzle line.
 - B. Get some small containers of equal size to put each nozzle into. Baby food jars or cut off "COKE" cans work well.
 - C. Put the throttle wide open, mixture full rich and turn the boost pump on. Allow fuel to flow for a minute or two or until fuel is flowing from all the nozzles signifying that all the air is purged from the lines.
 - D. Turn the boost pump off and move the mixture to ICO. Discard the fuel in all the containers.

TROUBLESHOOTING

- E. Insert nozzles in each container, leave the throttle open, turn the boost pump on and put the mixture to full rich. Allow the flow to run 15 to 30 seconds or fill the containers to half to three quarter full. Then return the mixture to ICO and turn off the boost pump.
- F. Set the containers on a level surface and check for approximate equal volume.
- G. Some variation is normal; a large variation indicates a restricted nozzle. While during the flow test, the nozzle spray pattern should be a straight pencil stream. Scattered or defused spray indicates a partially restricted or dirty nozzle.

Note: Nozzle spray pattern at idle is not always the same. Engine vacuum atomizes the fuel at idle flow conditions. Since vacuum is not present at this test, give more attention to the spray pattern of the nozzle at wide open throttle.

- H. Locate and correct the source of contamination before returning the aircraft to service.



TROUBLESHOOTING

NOZZLE CLEANING INSTRUCTIONS

6-8. The following procedure is approved for cleaning Airflow Performance injector nozzles.

1. Remove the nozzle from the engine using a clean 1/2" six point 1/4" drive deep socket.
2. Remove the fuel restrictor from the injector nozzle body.
3. Submerge all the nozzle parts in non etching parts cleaner, Acetone, MEK, or Hoppes Number 9 gun cleaning fluid. Use the submersion time prescribed by the cleaner manufacture for cleaning the parts.

SOME CLEANERS WILL ETCH THE NOZZLE MATERIAL.
PROLONGED SUBMERSION IN THESE TYPES OF CLEANERS WILL
RUIN THE NOZZLE BODY AND FUEL RESTRICTOR.

4. Sonic cleaning is also an acceptable method of cleaning injector nozzles. Use approved solvent in the sonic cleaner. Follow the manufactures recommendations for cleaning time.

WARNING

**DO NOT INSERT WIRE OR ANY SHARP OBJECTS
INTO THE NOZZLE ORIFICES.**

5. Remove from the solvent, rinse and blow dry.
6. Repeat the flow test as described in section 6-7.
7. Reinstall the injection nozzle in the engine as described in section 3-33 or 3-34.

TROUBLESHOOTING

TESTING THE FLOW DIVIDER

NOTE


The following procedure is intended as a troubleshooting aid only, and should not be construed as a calibration check of the flow divider assembly. If a question exists regarding the serviceability of the flow divider, the flow divider assembly should be returned for repair.

- 6-9. The following procedure will test the fuel flow division capabilities of the flow divider assembly.
 - A. Remove each nozzle line from the injector nozzle.
 - B. Get some small containers of equal size to put each nozzle line into. Baby food jars or cut off "COKE" cans work well.
 - C. Put the throttle wide open, mixture full rich and turn the boost pump on. Allow fuel to flow for a minute or two or until fuel is flowing from all the nozzle lines signifying that all the air is purged from the lines.
 - D. Turn the boost pump off and move the mixture to ICO. Discard the fuel in all the containers.
 - E. Insert the nozzle lines in each container, put the throttle to idle, turn the boost pump on and put the mixture to full rich. Allow the flow to run 30 to 60 seconds or fill the containers to half to three quarter full. Then return the mixture to ICO and turn off the boost pump.
 - F. Set the containers on a level surface and check for approximate equal volume.
 - G. A small variation is normal; a large variation indicates a restricted flow divider port. A restricted or kinked nozzle line is also possible.
 - H. Locate and correct the source of contamination or restriction before returning the aircraft to service.

TROUBLESHOOTING

FLOW DIVIDER CLEANING INSTRUCTIONS

- 6-10. The following procedure is approved for cleaning the flow divider in the field. Should a malfunction in the flow test occur after cleaning, the flow divider should be returned for repair.



1. Remove the flow divider from the engine.
2. Remove the four 10-24 screws from the cover, and remove the cover. There is a spring under the cover. Remove the flow divider spool valve and diaphragm as one assembly. Do not remove the diaphragm from the spool valve.
3. Remove the four 10-24 flat head screws from the base of the flow divider. Remove the base noting the position of the base relative to the flow divider body. The bottom of the flow divider body and base are lapped surfaces. DO NOT nick or scratch these surfaces. Remove the O-ring from the base.

TROUBLESHOOTING

4. Clean the flow divider body in non etching parts cleaner, Acetone or MEK. Do not submerge the spool and diaphragm in any cleaner. Wash the spool valve and diaphragm with Stoddard solvent. Blow off all parts with compressed air. Sonic cleaning is also an approved method for cleaning the flow divider body.
5. Insure that all the flow divider port slots are clean. A .006" feeler gauge is useful for this task.
6. Reassemble the flow divider in the reverse order. Replace the flow divider base O-ring if damaged. O-Ring P/N OR-027.7.
7. Repeat the flow test as described in section 6-9.
8. Reinstall the flow divider on the engine as described in section 3-26 and 3-27.

INTERMITTENT POWER LOSS

- 6-11. The most aggravating problem for a mechanic is trying to find the reason(s) for an intermittent power loss. Generally, this is not caused by the fuel controller. Many times it is caused by the interruption of either the fuel or air supply to the fuel controller. This may be due to such things as air in the fuel supply, dropping fuel pressure or a restricted induction air duct.

NOTE

The words power loss here refer to engine stoppage and the subsequent ability to restart the engine and obtain full power.

The fuel controller will not cause an intermittent/inconsistent power loss, even momentarily. If the fuel controller would be responsible for an engine stoppage, the cause of the stoppage (internal regulator failure) would remain and be readily apparent during the flow test and tear-down inspection.

If a power loss is accompanied by high fuel flow (measured by pressure gauge type flow meter), check the injector nozzles, nozzle lines, and flow divider for indications of a contamination problem. Check for water or moisture in the fuel. Given the right situation, this can form ice crystals in the fuel, temporarily blocking the injector nozzles. Once the engine has stopped, the ice will melt, and the fuel supply will be restored. High fuel flow (normally a pegged gauge) will accompany this situation. Ice could also block other fuel lines and not melt until after the aircraft has landed. If water is suspect in the fuel, drain and flush the entire fuel system.

TROUBLESHOOTING

Check the intake system, especially double wall ducting, for integrity. Also insure correct air flow into the fuel controller inlet. Refer to sections 3-21 through 3-23.

Check air filter for condition, particularly after operating in rain or wet conditions. Also test the alternate air door for proper operation.

Check the fuel filters for contamination (REMOVE ALL PAPER ELEMENT FILTERS FROM THE FUEL SYSTEM) such as water, salt, sand, fiberglass hairs, etc. Also ensure the filter housing is installed properly to eliminate any possibility of air entering the fuel supply.

Check the fuel hoses for deterioration or a flap of rubber near the fitting ends.

Check ignition and ignition components. Many times failure of these components symptomize a fuel system problem to the extent that leaning the mixture improves engine operation.

Check for valve train problems, loose valve guides, insufficient valve lash, stuck valves, tight valve guides.

Check exhaust system, muffler baffles, cracks, restrictions, deterioration.

Insure correct oil pressure especially during aerobatics and unusual attitudes. Loss of oil pressure can cause constant speed propeller operation to go to maximum pitch, causing the engine to load up and loose power.

Check for air in the fuel system, especially if the power loss is associated with a particular aircraft attitude.

Check for fuel vent pressure if power loss is associated with an increase in airspeed.

Insure that alternate air doors are in the full closed (alternate air) or full opened (ram air) position. Partial position of the alternate air valve will upset airflow into the fuel control causing surging and poor engine operation.

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION SEVEN

INJECTION SYSTEM NOTES

INDUCTION SYSTEM ICING

- 7-1. There two types of icing conditions, which are of considerable concern to the operator of any aircraft. The first is ice formation due to fuel vaporization, and the second is impact or atmospheric icing. The conditions that bring about these two ice formations are considerably different in their origin and, therefore, will be discussed separately.

VAPORIZATION ICING

- 7-2. Ice formation within carburetors due to fuel vaporization or refrigeration, is a result of a temperature drop at the point of fuel entering the air stream. The rapid vaporization of gasoline at the point of discharge can result in a 40 to 70 degree F drop in temperature. As moisture is always present in engine intake air, ice will form in the immediate area downstream from the discharge nozzle. In a carburetor this ice will usually form on the venturi and throttle shaft, and if permitted to accumulate will restrict the induction system to such an extent as to cause complete engine failure.
- 7-3. One of the main advantages of the FM series of fuel injection system is its "non-icing" characteristics. As fuel is discharged under pressure directly into the valve port of the intake manifold, the heat on the valve face completely eliminates the possibility of ice formation. Ice will not form in the venturi area of the fuel controller as no fuel is discharged in this area and the acceleration of the air across the venturi will not lower the temperature enough to cause ice to form.

ATMOSPHERIC ICING

- 7-4. Atmospheric (rime or impact) ice will usually form when flying through heavy rain, freezing rain, snow, or ice when the temperature is in the vicinity of 32 degrees F. This type of ice not only collects on the wing and propeller surfaces of the aircraft, but may completely restrict the inlet air scoop. Since this ice cannot be removed by application of heated air (carb heat), continued flight must be made on protected alternate air.

ICE AND SNOW

- 7-5. Power loss resulting from induction system restriction is often encountered when operating under these conditions. The restriction can form in the air inlet. Flight under there conditions must be continued by using protected alternate air.

INJECTION SYSTEM NOTES

FLIGHT DURING ADVERSE WEATHER CONDITIONS


- 7-6. Flight under certain weather conditions can result in the accumulation of ice in the air induction system. Observing normal pilot precautionary and corrective measures, as well as the airframe manufacturer's prescribed procedures, such as use of protected alternate air, should be adhered to whenever flying in icing conditions.

SECTION EIGHT

MAINTENANCE, LUBRICATION, AND STORAGE

MAINTENANCE

- 8-1. In general, very little attention is required between fuel controller overhauls (2000 hours). It is recommended that the following items be checked during 100 hour inspections and or annual inspections of the engine and airframe. More frequent removal of components and or hoses is discouraged since there is more chance of contamination getting into the system.



"IF IT AIN'T BROKE, DON'T FIX IT!!"

- A. After the first 3 to 5 hours of engine operation after installing the fuel controller on a new installation, remove and clean all fuel filters and strainers in the aircraft fuel system. Repeat after 10 hours of operation, 25 hours of operation and every 50 hours of operation there after. **Fuel control inlet filter should be inspected and cleaned (sonic cleaner recommended) at condition inspection.**
- B. Check all fuel lines for tightness and evidence of leakage. A slight fuel stain adjacent to the injection nozzles is normal and not cause for concern.
- C. Check tightness and lockwiring of all nuts, screws, and fasteners on the fuel controller and attaching hardware to the engine.
- D. Check the throttle and mixture control rod ends and levers for wear and tightness. Also inspect the idle linkage jam nuts for tightness and rod ends for wear.

MAINTENANCE, LUBRICATION, AND STORAGE

- E. Clean injection nozzles every 100 hours of engine operation. More frequent cleaning may be necessary if operating under severe dirty conditions. Do not clean nozzles more often than every 50 hours. It is not necessary to remove the nozzle body from engine. Remove the fuel restrictor from the body and clean as described in section 6-8. If the nozzle body requires cleaning follow the instructions in section 6-8.
 - F. If a slight degradation in full throttle fuel flow is seen over time, inspect the venturi for contamination. If the venturi is coated with oil and dirt, spray off the venturi and boost venturi with "Brake Kleen" or equivalent. Clean the boost venturi with a "Q-Tip" wetted with solvent. Do not insert sharp instruments or scratch the boost venturi. Wipe dry with a clean soft cloth.
- 8-2. Gasoline becomes stale due to prolonged storage. This stale oxidized gasoline acquires a very distinctive odor similar to varnish. This forms a gummy deposit on internal metal parts. This condition will not occur during normal operation of the engine as fresh fuel will be circulating through the fuel controller. **Installations in aircraft running auto fuel should start, take off and land using avgas. This will flush auto fuel from the metering system keeping varnish from fouling components.**
- 8-3. If the aircraft will not be used or run for more than three months, the fuel controller should be drained of fuel and filled with a good grade of No. 10 non detergent oil. If this procedure is not followed then the engine should be run a minimum of 10 minutes every three months.

LUBRICATION

- 8-4. There is very little need for lubrication of the injector in the field. Place a drop or two of engine oil on each end of the throttle shaft so that it will work into the throttle shaft bushings. Recommended lubrication of these bushings is every 50 hours.
- 8-5. Follow the aircraft manufacturer's, or air cleaner manufacturer's instructions for cleaning and oiling the filter element. A filter element replaced with an excessive amount of oil on it can cause fuel metering difficulties as the excess oil will be drawn into the fuel controller inlet and into the venturi. This can greatly effect the metering characteristics of the fuel controller.

PREPARATION FOR STORAGE

- 8-6. Units taken out of service for more than three months should be removed from the engine and preserved. Use the following procedure for preserving the fuel controller.
- A. Remove the fuel controller from the engine. Drain all residual fuel from the fuel controller.

MAINTENANCE, LUBRICATION, AND STORAGE

- B. Introduce 10 weight oil by gravity into the fuel inlet on the fuel controller. Use only clean filtered (10 weight, 10 micron filtration). Add oil until the oil runs out the outlet fitting. Exercise caution when adding oil to keep oil from entering the air section through the venturi. Although no damage will result to the parts in the regulator exposure to oil may effect the air signals from the venturi. This effect will be more noticeable in extremely cold environments.
- C. Drain the excess oil from the fuel controller. A film of oil on the internal parts of the fuel section is sufficient to preserve the controller.
- D. Replace caps on the fuel inlet and outlet.
- E. Pack the fuel controller in a dust proof container.
- F. If the fuel controller is to be stored or shipped over salt water, the following should be observed:
 - 1. Spray the external surfaces of the fuel controller with clean preserving oil. Do not spray oil in the venturi or impact tube.
 - 2. Pack the fuel controller in a clean dust-proof packing, wrap the packing with moisture-proof material and seal. Pack the fuel controller in a suitable shipping case.

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION NINE

OVERHAUL PERIOD

Airflow Performance fuel controllers are not field repairable. There are no rebuild kits available and specialized test equipment is required for re calibration of the fuel controller. With the exception of the field maintenance and troubleshooting described in the previous sections, the fuel controller and components must be returned to Airflow Performance for overhaul and or re calibration.

TIME BETWEEN OVERHAUL

- 9-1. The time between overhaul (TBO) for all fuel controllers and fuel system components is the same as the recommended TBO for the engine, not to exceed 2000 hours. Time between overhaul is also dependent upon the type of service and the installation the fuel controller is subjected to. An installation subjected to hard aerobatics may not complete the full TBO due to higher vibration levels that are encountered in this type of service.
- 9-2. Regardless of time in service, overhaul is recommended based on an accumulated calendar time of 12 years for fuel control units and 8 years for flow dividers. This is from the date of manufacture or last overhaul date.
- 9-3. A complete overhaul is required regardless of accumulated time in use when the fuel controller or fuel system component has been subjected to severe environment such as but not limited to:
 1. Engine fire, external or prolonged air intake manifold fire, accident, or when service history of the fuel controller is unknown.
 2. Contaminated fuel such as water, sand, rust, etc.
 3. Fuel that does not meet the engine manufacturer's requirement may be detrimental to engine operation. If a non-specified fuel is inadvertently pumped into the aircraft fuel system and drained, fuel controller overhaul is not required.
 4. If uncertain that the fuel controller or components requires service or overhaul, contact Airflow Performance for consultation.

OVERHAUL PERIOD

PREPARATION FOR SHIPMENT

CAUTION: FEDERAL REGULATIONS CONCERNING SHIPMENT OF FUEL UNITS REQUIRE THAT THE FUEL SECTION BE SEALED WITH CAPS CAPABLE OF KEEPING FUEL FROM LEAKING. DO NOT USE MASKING TAPE OR OTHER NON APPROVED MATERIALS FOR THIS PURPOSE.

- 9-4. Install caps or AN style pressure caps to the fuel inlet and outlet.
- 9-5. Place the fuel controller in a clean plastic bag to protect the air section from packaging materials. Do not use tape for this purpose.
- 9-6. Place the sealed fuel controller in a suitable container with sufficient packaging materials to prevent damage during shipment.

APPENDIX A

FUEL SYSTEM SCHEMATICS

The following schematics are for numerous installations. There are variations of the descriptions also. The table below describes a typical application where the particular schematic may apply. If you have a unique application where the schematic does not quite apply, contact Airflow Performance for further information.

INDEX OF APPLICATIONS


SCHEMATIC #	DESCRIPTION	TYPICAL APPLICATION
1	Diaphragm engine driven fuel pump with electric boost pump mounted in airframe.	RV series, Lancair, Glasair; preferred installation using Lycoming engines with down draft cooling. This is a typical tractor engine installation
2	Diaphragm engine driven fuel pump with electric boost pump mounted on firewall.	Long EZ, Cozy, typical Lycoming installation on rear engine aircraft using updraft cooling. The boost pump and filter are mounted low on the firewall in the stream of incoming cooling air.
3	Single fuel tank installation. Diaphragm engine driven fuel pump with electric boost pump in airframe.	Pitts, One Design. Lycoming engine installations with down draft cooling.
4	Mechanical vane or gear type engine driven fuel pump. Dual boost pump has no relief, uses relief on engine driven pump.	Automotive engine conversions, V-8 applications. S-51, FEW 51, Legend, are typical examples.
5	Dual electric fuel pump package. No mechanical pump is used.	Automotive engine conversions. Subaru, V-8, Mazda. This is an aerobic installation. Fuel return from pump package goes to header tank.
6	Dual electric pump package. No mechanical fuel pump.	Automotive conversions. Fuel return is sent to main fuel tanks.
7	Mechanical vane pump with internal bypass and external relief. Dual boost pump with no relief.	Automotive V-8 conversions. S-51. Return fuel is sent back to each tank. Return check valves keep cross flow from happening if aircraft is in a bank.

APPENDIX A (Continued)


INDEX OF APPLICATIONS

SCHEMATIC #	DESCRIPTION	TYPICAL APPLICATION
8	Mechanical fuel pump with internal bypass and external relief. Single boost pump package with no relief.	AMW engine. Aerobatic installation. Return fuel is sent to header tank.
9	Mechanical fuel pump with internal bypass and external relief. Single boost pump package with no relief.	AMW engine. Return fuel is sent to each fuel tank through a ganged selector valve.
10	Mechanical fuel pump with internal bypass and external relief. Single boost pump package with no relief.	AMW engine. Return fuel is sent to one tank. The fuel tanks level them selves through a inter connected feed line.
11	Dual boost pump package feeding engine driven fuel pump.	Seawind. Used for starting and emergency back up. One pump is energized for high altitude and cruise flying.
12	Engine driven fuel pump with internal bypass and relief (Romec).	High output six cylinder Lycoming applications. Automotive conversions using Romec type engine driven fuel pump.
13	Dual electric fuel pump package.	Low horsepower Automotive conversions, Subaru, VW, Mazda. Relief valve for fuel pumps is in side fuel controller
14	Turbocharged Lycoming application. Romec engine driven fuel pump	Lancair IV or IV P application. This is a specialized installation using a modified Bendix fuel controller.
15	Turbocharger systems installation.	Lancair IV P. A typical installation for a turbocharged engine


FUEL SYSTEM SCHEMATIC 1




APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 2




APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 3




APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 4



APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 5




APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 6




Rev D

A-8


APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 7




APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 8




APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 9




APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 10




APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 11



APPENDIX A (Continued)
FUEL SYSTEM SCHEMATIC 12




FUEL SCHEMATIC 13




REVISIONS				
ZONE	REV	DESCRIPTION	DATE	APPROVED

PROTECTIVE COAT:	ROTAX FUEL SYSTEM SCHEMATIC DUAL PUMPS WITH SURGE TANK			
HEAT TREAT:	AIRFLOW PERFORMANCE, INC.			
MATERIAL:	SIZE A	FSCM NO.	DWG NO.	REV
DATE: 1-12-10	SCALE	DRAWN BY: DJR	APPROVED BY:	


FUEL SYSTEM SCHEMATIC 14






APPENDIX A (Continued)


Dual electric pump package shown mounted to a .062 aluminum plate. The pump components and filter assy. are mounted to the plate with Adel clamps. The plate is mounted to the airframe with Adel clamps.



Boost pump and filter assy. mounted to the firewall. The complete assy. will be enclosed in an insulated box.




Boost pump filter assembly enclosed in insulated box. Blast air is run through the box for cooling.




APPENDIX A (Continued)

Long Ez installation. Boost pump package mounted on lower part of firewall. Incoming cooling air keeps pump cool. Engine is up draft cooled.

Boost pump package




Installation using dual electric pumps. Dual pump package mounted on firewall. Pumps need to be in an enclosed box if this engine is to be down draft cooled.




V-8 conversion. Belt drive mechanical fuel pump shown. Ideally the pump should be mounted as low as possible. This will help with hot operation at low engine speeds. Vapor lock may be a concern with this installation.


Belt driven engine driven fuel pump



V-8 conversion. Mechanical engine driven fuel pump driven off the back of the dry sump oil pumps. The dry sump pump stack is cog belt driven off the crankshaft nose. This installation offers low positioning of the fuel pump to minimize suction lift of the fuel.




This shows the fuel supply line to the engine driven pump. The correct installation using bulkhead fittings to bring the fuel supply through the firewall and fire sleeved hose is seen in this photo. Care must be taken to avoid the use of 90 degree fittings on the suction side of the fuel pump on high horse power applications. The more correct way would be to use a straight bulkhead fitting and a full flow 90 degree hose end to eliminate flow pressure drop.




Fuel supply bulkhead fitting.

APPENDIX A (Continued)


A nice tidy installation of the pressure gauge connections is shown here. Again the correct use of bulkhead fittings to route the hoses through the firewall. Note the use of braided stainless steel Teflon lined pressure hoses on the engine side of the firewall.



Hard plumbing is used on the cabin side of the firewall. Here the pressure lines come through the firewall. The 3/16" lines are neatly bundled into a conduit.



Boost pump mounted high on the firewall. Notice there is no box enclosing the pump or the gascolator (shown in the lower left hand corner of the photo). This will certainly cause fuel vapor problems and poor engine running under hot conditions. An installation like this may cause engine stoppage at low power settings.




Boost pump package

Gascolator


APPENDIX A (Continued)

Here's an example of a builder wanting to make an unscheduled landing. The use of hard plumbing in the engine compartment will pick up heat and is subject to failure due to vibration.



Aluminum fuel line. NOT
RECOMMENDED


Fuel controller hook up for systems using electric fuel pumps. This fuel controller has the relief valve for the fuel pumps built into the regulator section. This keeps fuel circulating through the fuel control regulator keeping it cool.



Fuel inlet
Fuel return


Metered fuel outlet

Since only air flows through the intake manifold, the fuel controller can be mounted on elbows and adapters to facilitate the installation. Airflow Performance has many different elbows in stock to fit various engines and installations. Phenolic spacers can also be used to space the fuel controller or elbow.




APPENDIX A (Continued)


Airflow Performance manifold systems for automotive conversions. These fit most V-8 and V-6 engines. Injector nozzles are placed so that fuel is discharged near the intake valve.



For installations where cowling clearance is a problem, a low profile plenum is available.



This Subaru engine has a siamesed intake port. The injector nozzles are installed in the head so that the fuel is discharged at the back of the intake valve.



Injector nozzle

A machined aluminum spacer between the sump and the elbow provides clearance for the inverted oil system fittings and hoses and the fuel controller throttle body on this Lycoming 320.





Aluminum spacer


APPENDIX A (Continued)

Maintainable fuel filter installation P/N 1090079. The filter is mounted to the firewall with two MS21919WDG26 clamps. Notice the blast air hose and shroud.

Blast air shroud.



Glasair boost pump installation. Assembly is installed behind seat in aircraft. P/N 1090079 filter is installed before the boost pump. A high pressure Fram cartridge filter is installed after the boost pump. This filter is required to filter the small fiberglass particles from the fuel. It is installed on the pressure side of boost pump so that the boost pump can force the fuel through the filter



Boost pump and gascolator installed on the firewall of an up draft cooled Long EZ. The gascolator is installed on the boost pump inlet with the pump return teed into the gascolator inlet.

APPENDIX A (Continued)



Boost Pump and Filter mounted in the tunnel of an RV-10

THIS PAGE INTENTIONALLY LEFT BLANK


FUEL CONTROLLER INSTALLATION

This section contains information pertaining to hook up and installation of the fuel controller and associated controls. Some of the photos show installation procedures for installing brackets provided on kits for Van's RV series aircraft.


Fuel injection kits that include the brackets and hardware may require that the sump mounting studs be longer. This picture shown the installation of longer studs that comes with an RV kit for a 320 Lycoming. The new studs should be installed with a high temperature or stud grade Loctite. In this case a 5/16 X 2" stud is installed.



Fuel controller mounting adapter for a 320 Lycoming. The throttle and mixture control cable brackets are adjustable. The correct length needs to be determined before the fuel controller is mounted to the engine. Mount the bolt heads on the cut out side of the bracket. This will give clearance for the bolt head to the sump when the adapter plate is mounted to the engine. Excess cable bracket may be cut off. AN3-6A bolts, #10 washers and locknuts are used to secure the cable brackets to the adapter.



Install a gasket between the sump and the adapter.



APPENDIX B (Continued)


Install the other gasket on the adapter before mounting the fuel controller.




For RV kits or engines using the Airflow cable brackets and adapter for the 360 Lycoming, the bolt pattern is matched to the FM-200 with this adapter. Mount the cable brackets in the correct location for your throttle and mixture control cables before mounting the assembly. Heat may be required to remove the existing studs in the sump. Install a gasket between the sump and the adapter.



The adapter for the Lycoming 360 is fastened in place using 4 5/16-18 X 3/4" socket head cap screws. Use Loctite when securing these screws.




Install the gasket on the adapter before mounting the fuel controller.




APPENDIX B (Continued)

Metered fuel hose

Throttle and mixture cables are attached to a bracket that is attached to the side of the cold air plenum on this Lycoming 540. Notice the routing of the metered fuel hose, which is correctly fire sleeved and run through a grommet on the lower cylinder baffle. On most Lycomings this is run between cylinder one and three.




Use control cables with solid threaded ends. Rod ends with spherical bearings are recommended for attachment to throttle and mixture control levers. This will give positive movement of the controls. Motorcycle type cables with return springs are not recommended.




APPENDIX B (Continued)

Engines using the Airflow cable bracket assembly (as in RV kits) as shown are typically mount the fuel controller and cable bracket assembly with the regulator and brackets toward the accessory section of the engine. This is mounted to a Lycoming 320 sump.




Some engine installations require a manifold drain. This keeps fuel from accumulating in a low area of the intake manifold. The fuel can drain out when the engine is shut off, but the fitting will seal off during engine operation to prevent a vacuum leak. P/N 1090138 is shown installed in the bottom of this cold air plenum. The fitting installs with 1/8 inch pipe thread. AN-4 tubing or hose attaches to the other end of the drain assembly to route excess fuel away from the engine compartment.



The drain fitting can also be installed in the bottom of an intake elbow.

Manifold drain assy.
P/N 1090138

Turbine type fuel flow meter installed in the metered fuel line. Check with the manufacture specifications for correct plumbing of the sending unit. 90 degree bends are generally not permitted on the inlet side of the flow meter.



Flow meter inlet


Turbine flow meter
sending unit.

APPENDIX B (Continued)


Supplied throttle and mixture control cable brackets may have to be modified for a specific installation. This may be necessary to provide necessary clearance for exhaust systems, landing gear mounts etc. Airflow Performance supplied throttle and mixture control cable brackets must be modified to clear nose landing gear structure on RV-6A and RV-8A aircraft.



Angle aluminum has been riveted to the supplied throttle cable bracket to provide correct alignment of the cable and provide necessary clearance of other components.



Mixture control cable attachment. Use suitable material to provide adequate stiffness of the bracket



APPENDIX B (Continued)

On Lycoming 4 cylinder front entrance sump engines, rotate the adapter to install the fuel control with both the throttle lever and mixture control on the bottom. This facilitates the installation of the throttle and mixture control cables to the fuel control unit.



Depending on the type of throttle and mixture control cable control that is used, a variety of different cable brackets can be fabricated to facilitate hook up.




Shown here is a RV-8 with Lycoming IO-390X engine.





APPENDIX B (Continued)

In this RV-10 installation, the supplied throttle cable is shown installed



An additional piece of angle aluminum has been installed on the throttle cable bracket to facilitate installation of the throttle cable




An installation on a Lycoming IO-540 with Cold Air Induction

APPENDIX B (Continued)




Installation in a Pilatus P-3 with GO-435
Installation in a Pilatus P-3 with GO-480



APPENDIX B (Continued)



A Long EZ installation using an 85-degree elbow and phenolic spacers locates the fuel control into air inlet.




Fuel Control mounted on the inlet of a twin turbo charged 540. The carbon fiber duct feeds the two turbo charger compressor inlets.

APPENDIX B (Continued)



Installation on a super charged 540. The fuel control is installed on the inlet side of the super charger compressor.



Front sump cable hook-up on RV-6A.


APPENDIX B (Continued)



Throttle and Mixture Control cable hook-up on RV-8 360 up draft sump.



APPENDIX B (Continued)



Control Cable hook up on a front sump 360 with FM-150 in a RV-8



Throttle hook up on FM-200A with front sump 360.

APPENDIX B (Continued)



Mixture hook up on FM-200A with front sump 360.

THIS PAGE INTENTIONALLY LEFT BLANK


AIR INLET

The following photos show examples of possible air inlet configurations. It is important to get cold outside air for maximum engine performance. It is also wise to have an alternate source of air in case the primary source of air to the engine is obstructed.

Installations using Airflow Performance air box inlet. These approach clamp rings are used with Van's airbox. The air box mount plate is positioned on the throttle body and a pinch bolt (1/4 - 20 X 7/8 soc hd cap screw) is used to secure the approach clamp ring to the throttle body. Apply some Loctite to the pinch bolt.



The air box mount plate is secured to the approach clamp ring with four 1/4 - 20 X 3/8 hex head bolts with star lock washers and plain washers. The plain washer goes against the mount plate, the star washer goes against the bolt head.



Air box mount plate bolts.

WARNING
The approach clamp ring must be on the inside of the air box. The air box mount plate bolts must be on the outside of the air box

Due to the high gain venturi that is used on the Airflow Performance fuel controllers, direct ram air can be introduced to the throttle body with no adverse effects on fuel metering.



Ram air inlet.

APPENDIX C (Continued)


When using Airflow Performance alternate air duct, the assembly is attached directly to the throttle body and secured in place with a tee bolt band clamp. This assembly provides a means to have unfiltered ram air and filtered alternate air. On this Skybolt installation the alternate air valve is actuated with a cable. The cable bracket is attached to the tee bolt band clamp.




Filtered air is pulled into the engine when the alternate air duct valve is closed. A K&N filter provides air filtration in this case. Scat hose could also be attached to this leg to a remote air filter.



A simple hose mates up to the cowl opening to duct the ram air into the throttle body.



Pulling inlet air directly from the cowl area can cause rich mixture and poor engine performance due to heated air under the cowl. Care must be taken on installations like this to insure adequate supply of cold outside air to the air cleaner.




APPENDIX C (Continued)

An opening in the cowl with clearance to provide for engine movement ducts ram air directly into the throttle body on this aerobatic airplane. Keeping the annular clearance less than 1/4 inch will minimize the amount of hot air from the engine leaking into the inlet.




A short piece of aluminum tubing is used to duct the air into the fuel controller.

Aluminum tubing ducts air into the fuel controller. Clearance is provided to the cowl to provide for engine movement




While this looks like a swoopy installation, the tube protruding through the cowl to provide inlet air creates a large pressure drop into the fuel control inlet. A large increase in performance can be gained by radiusing the tube inlet.

Sharp edge entrance. Poor for air flow.



Poor engine performance, surging, rich or erratic operation may result when test running the engine with the cowl off. Here the engine is run up with the fuel control inlet perpendicular to the prop blast. The blast air flowing across the fuel control inlet will give incorrect air flow measurement of the venturi causing incorrect fuel metering.

Fuel control inlet perpendicular to prop blast.




APPENDIX C (Continued)


A smooth radiused inlet on this cowl will provide maximum air to the fuel controller. Care must be taken to place the inlet in a high pressure area on the cowl. Screens in front of the inlet will restrict airflow and cause turbulence in the throttle body inlet.




Some engines have rear entrance sumps. On these installations it may be simpler to pull the inlet air from a flush scoop on the side of the cowl. This will not provide as high of inlet ram as an opening on the front of the cowl.



A Bracket air cleaner is adapted to an aluminum air box. The air cleaner assembly is below the cowl to pick up outside air. Not exactly a low drag installation but it works well on this aerobatic aircraft.



Scat hose is a simple way to duct air into the fuel controller. Care must be taken to reduce pressure drop through the duct. A larger size than the throttle body should be used to reduce flow loss through the hose. Keep bends and run length to a minimum.




APPENDIX C (Continued)


An automotive air cleaner is mounted directly to the fuel controller throttle body. There is no need to duct air in on this installation since this automotive V-8 conversion installed in a helicopter is exposed to outside air.



A large K&N filter is used on this rotary engine. Consideration must be given to air cleaner area with respect to engine brake specific air consumption (BSAC). Two stroke in particular have a higher BSAC and are sensitive to inlet pressure drop than four stroke engines. Therefore a larger than normal air filter is required on these engines.




Lycoming 320 with Van's air box installation. As with the 360 installation, the bottom of the fiberglass box holds the air cleaner element against the air box mount plate. There is no intermediate plate holding the air filter in place.



APPENDIX C (Continued)

This installation uses filtered ram air only. A tapered fiberglass duct surrounds a tapered air filter. A model airplane spinner gives smooth air flow around the air filter




Here's the same installation with the cowling on. The tapered duct mates up with a radiused inlet on the cowling.



This unfiltered ram air inlet on this EDGE 540 gives optimal manifold pressure during aerobatics. The inlet has a 7 degree taper into the throttle body. Notice the radius right at the air inlet.



APPENDIX C (Continued)



Inlet air horn.
Connected to
cowling

This installation uses a carbon fiber inlet that is attached to the cowl. The snout of the air horn lines up with the inlet of the alternate air duct. A 1/8" gap between the air horn snout and the alternate air duct allows engine movement but there is no flexible connection to the alternate air duct. The close clearance allows immeasurable air leakage to the ram inlet.


Cowling installed with Ram air
door open.



APPENDIX C (Continued)




Composite air inlet attached to FM-100 in Long EZ installation. Air inlet points into duct that feeds cold air into the engine compartment.



Ram/Alternate Air Duct on RV-8A.

APPENDIX C (Continued)



Ram/Alternate Air Duct on RV-8A



Down draft cooled Long EZ.


APPENDIX C (Continued)

THIS PAGE INTENTIONALLY LEFT BLANK

FLOW DIVIDER INSTALLATION


Flow dividers are used when the engine is not level at idle (tail dragger aircraft) or when the injector nozzles are below the distribution point. The flow divider will divide the metered fuel equally among the ports that are connected to it, regardless of the height of the injector nozzles to each other. The flow divider needs to be mounted on the cool side of the engine (where the cooling air is coming in) and in some cases an insulator block and or blast air will help in hot low power operation. Also a vent allowing the hot air to escape above the flow divider after shut down is helpful for hot starts.

Flow divider bracket P/N 2090148 can be used to mount the flow divider to most Lycoming engines. Mount the bracket as shown between cylinders #1 and #3. The bracket hardware kit P/N LFDHDKT has the necessary spacers and bolts to attach the bracket to the engine.



An alternate method of mounting is to flip the flow divider upside down. This gives a little lower profile for a tight cowling. The four 10-24 screws need to be lock wired.

Lock wire screws after mounting flow divider to bracket.




Standard Lycoming 'L' shaped brackets can also be used to mount the flow divider. This provides a center mount on the engine. Notice the fuel flow gauge line plumbed into one of the nozzle lines.

#3 restricted fitting for fuel flow gauge. Old flow divider design shown. New flow divider design has "GAGE" port to connect gage fitting directly to flow divider body without restrictor in fitting.




APPENDIX D (Continued)

Side mount flow divider installation on Lycoming 540. Mount Airflow Bracket P/L 2090148 using mount kit P/N LFDHDKT between cylinders #3 and #5.



Additional flow divider bracket spacer


Install the 45-degree nozzle line fittings and slide bracket mounting bolts through the bracket. Note: omit washers under bolt head for clearance. Then mount the flow divider to the bracket. Don't forget to lock wire the four 10-24 mounting screws on the bottom side of the bracket. Some Lycoming crankcases (narrow deck Lycomings) may require additional spacers for clearance of the flow divider bracket.




For updraft cooled engines requiring a flow divider, the flow divider can be mounted off a bracket, which is mounted to the sump. The flow divider can be mounted in any position.



APPENDIX D (Continued)




On this FM-150 installation the fuel flow meter is mounted between the fuel control and flow divider. A short hose with a full flow 90 connects to the inlet of the flow meter from the metered fuel outlet of the fuel control. Straight fittings are installed in the flow meter inlet and outlet (in this case AN816-4-4D). A grommet supports the hose as it passes through the lower inner cylinder baffle. Note that the hose supports the flow meter. It is not attached to the engine. This keeps vibration inputs to the flow meter to a minimum. Also of importance is the metered fuel hose is made a short as possible. This helps with hot re-starts. After leak check the flow meter will be wrapped in fire sleeve to protect it from engine heat.



In this case the shortest route for the metered hose is routed from the fuel control was behind the accessory section. To keep the flow meter on the cold side of the engine the metered hose passes through a grommet in rear baffling. The flow meter is then attached with a short hose connecting the flow meter outlet to the flow divider inlet. Again the hose supports the flow meter. On this installation the flow meter is left exposed so that cooling air in flight keeps the component cool.


Manifold systems come complete with all components mounted. The flow divider is typically mounted off the plenum. This keeps the flow divider somewhat insulated from engine heat.



DISTRIBUTION BLOCK INSTALLATION

Distribution blocks can be used as an alternative to the flow divider under the following circumstances. It must be mounted below the injector nozzles. The nozzles must be close to the same level (like in a tricycle gear installation). The distribution block must be on the cool side of the engine. The distribution block has a pressurizing valve built into the assembly. This keeps fuel from draining back out of the nozzle lines at shut down, and also keeps fuel from draining into the system. There are two pressure ratings for the valve. 1 PSI. This can be used on aircraft where the wing tanks are at or below the level of the engine. 5 PSI. This is used on installations that use electric fuel pumps only for fuel delivery, or where the wing tanks are above the level of the engine.

Here's an installation for an up draft cooled Lycoming in a Long EZ. The distribution block is mounted to bottom of the crankcase with two 5/16-18 bolts using bracket P/N 2090136. This installation is using the purge valve option, which is attached to the distribution block inlet. The bracket also provides for mounting this component.




Metered fuel hose.

Distribution block bracket

Distribution block assembly.

A phenolic insulator block is mounted between the distribution block bracket and the engine crankcase to provide heat insulation.



Insulator block installed between bracket and crankcase.

APPENDIX E (Continued)




Distribution Block and Purge Valve mounted to plate. This assembly is mounted to the oil sump on an up draft cooled Long EZ installation.

This installation will surely give problems. The distribution block is mounted just above the cross over exhaust (see the arrow). Heat from the exhaust will boil the fuel in the block at low power settings. Also notice the use of non-fire sleeved hose and hard plumbing to the inlet of the fuel controller. Both create unscheduled landings.




Distribution block installation on Subaru engine installation. A sturdy aluminum bracket bolted to the head provides the mount while an insulator block keeps heat transfer from the engine from heating up the block. Blast air is also provided to the distribution block assembly to keep the fuel cool in flight.




BLEED AIR NOZZLE RAIL

For turbo charged applications and applications where the nozzle discharge is higher than the vent on the nozzle body (primer port installation), a bleed air rail is used. The schematic shown below shows the hook up for a ‘blow through’ system. This can only be used if the manifold pressure will not exceed 31” Hg MAP. Typically this is called turbo normalizing. The bleed air nozzle rail connects directly to the turbo charger outlet. Short pieces of 3/16” hose connect the bleed air rail stubs to the nozzle shroud. Clamps are used to secure the hose connections.



The bleed air rail assy. P/N 2090137 is shown here on a 360 Lycoming. The installation here is on a naturally aspirated engine and the bleed air rail serves to collect any fuel that may leak out on the injector nozzles that are installed in the primer ports. Notice the connection of the rail to the nozzle shroud tubes with the hose and clamps.




Notice the connection of the rail to the nozzle shroud tubes with the hose and clamps.


APPENDIX F (Continued)

Bleed air rail on this manifold system is for a turbo normalized (in this case a supercharger is used) induction system. The end of the bleed air rail will be connected to the supercharger discharge.

A -6 hose will be connected to the supercharger outlet from each rail (one per side)



On installations where bleed air rails are used on naturally aspirated engines, the rails can be vented via -6 hoses into the air cleaner box. This allows filtered air to be drawn into the nozzles.



Bleed air rail hose

Filter box mounting plate.

APPENDIX F (Continued)




Bleed Air Rail Assembly

#6 Vent hose

Naturally aspirated GO-480 with injector nozzles installed in the primer ports. The bleed air rail is vented overboard through a #6 hose.

Installation in a Lycoming powered 360 Long EZ.

The hoses from the bleed air rails are vented to the air inlet after the air cleaner. This admits filtered to the bleed air rail.




Bleed Air Hoses

APPENDIX F (Continued)




Long EZ Bleed Air Rail installation.




Supercharged 540. Bleed Air Rails are inboard on the cylinders.

Hoses connecting to nozzle shrouds


APPENDIX F (Continued)



RV-10 with pressure cowl Bleed Air Rail installation.




APPENDIX F (Continued)



Installations having tight pressure cowls using naturally aspirated engines may require that the injector nozzles be vented to a higher pressure. In these installations the engine has turbo injector nozzles installed and the bleed air rail is vented to ram pressure through the front of the cowl opening.

BLEED AIR SHUTTLE VALVE


For turbo or supercharged installations where the manifold pressure will exceed 31" MAP, the fuel controller must be mounted on the inlet side of the compressor. With the inlet throttled, the nozzles must be vented to atmosphere when the throttle is at idle or the manifold pressure is below ambient and when boost is made the nozzles must be vented to compressor discharge pressure. The bleed air shuttle valve accomplishes this task. The schematic below shows the hook up in the system for a 'draw through' system.




Bleed air shuttle valve assembly plumbed for a supercharged V-8 installation.

Manifold pressure connection for shuttle valve.

Bleed air rail connection from shuttle valve



APPENDIX G (Continued)



Bleed air shuttle valve installation on Lycoming IGSO 480.

Bleed air shuttle valve.


Valve assy. should be mounted horizontal as shown or with the ambient air screen up (preferred).

Shuttle valve hose to bleed air rail.

Nozzle bleed air rail


NOZZLE LINE INSTALLATION

The following deals with stainless nozzle line installations. The material can be easily bent by hand or with a small tube bender.



Use the above sketch as a guide for bending nozzle lines. Stainless lines will work harden. Do not attach to structures with relative motion (like the engine mount and the engine). Lines need to be supported every 6 to 8 inches. Use MS21919WDG2 clamps to clamp nozzle line to support structures.

On down draft cooled Lycoming's the nozzle lines are routed and supported on the push rod tubes. 'L' brackets support the lines as they cross the center of the crankcase.




APPENDIX H (Continued)

Attach “L” brackets to the crank case centerline bolts. Longer bolts 1/4-20 X 1 1/2” are used with a star lock washer MS35333-40. Use the existing 1/4-20 plain nut.



On installations using down draft cooling but the injector nozzles are installed in the primer ports, the nozzle lines are routed through the baffling as shown. Bore a 9/16” hole to install the MC-9307K41 grommet, which will support the nozzle line as it passes through the baffle.




Route the nozzle line beside the valve cover and to the injector nozzle at the primer port.




APPENDIX H (Continued)


For a center mounted flow divider on a Lycoming 540, there are 4 21” nozzle lines and two 17” nozzle lines. Route and clamp the lines as shown using the four “L” brackets on the 21” lines. Support the lines as they are routed down the push rod tubes with cushion clamps.



For Lycoming 540's with side mounted flow dividers, route and clamp the lines as shown.




APPENDIX H (Continued)



On up draft cooled engines, the lines are routed under the engine and attached to injector nozzles in the primer ports. Keep lines away from the exhaust pipes. Route and clamp them to the intake pipe.

Support the lines along the oil sump using “L” brackets to provide stand offs from the oil sump mount bolts to the nozzle line clamps.




APPENDIX H (Continued)


Another view of the clamping arrangement for securing the nozzle lines on an up draft cooled engine.



Routing of the nozzle lines through the baffle on a Lycoming IGSO-480.




Nozzle lines routed on a six cylinder Franklin engine. With the lines in close proximity to the exhaust pipe, some kind of heat shield must be fabricated to keep the fuel from boiling in the lines.




APPENDIX H (Continued)


This installation is on a Subaru EA 81 engine. Note how the nozzle line is teed to each injector nozzle. There is one line to each side of the engine, and then the line is teed off to each nozzle. This keeps the velocity of the fuel up in the nozzle line since the engine uses little fuel at idle and low power. This helps with fuel boiling in the lines and removes the air from the lines faster on start up.



This installation is on an AMW three cylinder two-stroke engine. The injector nozzles are installed in the boost port of the cylinder.



Injector nozzles mounted in the intake pipe of this four cylinder Franklin engine. Note the vent lines connected to the nozzle shroud tubes.



Injector nozzle


Nozzle vent tube

PURGE VALVE INSTALLATION

The following shows possible purge valve installations. The important thing to consider in the installation is to keep the connection between the purge valve and the flow divider or distribution block as short as possible. The purpose is to purge as much of the metered fuel in the system as possible. Also a fuel return to a fuel tank is necessary to accomplish the purge operation. Returning the fuel to the fuel pump inlet will do nothing but circulate the hot fuel and vapor through the system. This will accomplish nothing. Also capping the return line and using the purge valve, as a shut off valve will not allow correct operation of the valve.


Here the purge valve is connected directly to the flow divider.

Notice how the purge valve stop and two mounting screws are lock wired together. If removal of the valve is necessary, make sure to re lock wire the purge valve stop screw. Failure to do so will result in sudden stoppage of the engine if the screw backs out.



The stop lever is marked "R" and "ICO". When "R" is against the plastic stop the valve is in the run position. Likewise when "ICO" is against the plastic stop, the valve is in the purge or bypass return position. There is some valve 'dead band' that means that the valve will not start bypassing as soon as the lever is moved from the "R" position

Purge valve / flow divider assembly mounted to Lycoming engine. The purge valve inlet is between cylinders 1 and 3.




APPENDIX I (Continued)

Purge Valve installation on a Lycoming engine. The purge return is not yet hooked up in this photo. The purge return is typically -4, but a line as small as 1/8" could be used as approximately only 4 to 6 GPH is flowing through the valve during the purge operation.



Purge return

Purge inlet




This is a remote mounted purge valve. Note the short -4 hose from the purge valve outlet to the flow divider.

Purge valve outlet to flow divider


Purge valve inlet.
Metered fuel hose from
fuel controller

A modification of the purge valve bracket. A return spring has been installed to return the valve to the "R" position in the unlikely event that the cable would fail.




APPENDIX I (Continued)


Installation of the purge valve mounted to a distribution block. This is a typical installation for a Long Ez or Cozy, or where the engine is up draft cooled.



For installations where a pressure cowl is used or the cowling is tight to the engine, a horizontal mount purge valve can be used. The actuating lever is mounted down. The metered fuel hose is routed around the front of cylinder #1 on this four cylinder Lycoming. This is a typical installation on RV-4's and Lancair's.




A remote purge valve installation on this Lycoming 540. A short fire sleeved metered fuel hose connects the purge valve outlet to the flow divider inlet.




APPENDIX I (Continued)

A number of different levers are available to fit different clearance requirements. Shown here is a standard throttle lever (P/N 2090118) installed. An offset lever with 1 1/2" offset (P/N 2090156) and a reverse offset lever with 1/2" reverse offset (P/N 2090155) are available from Airflow Performance. The purge valve comes standard with a straight (P/N 2090083) lever.




There are many installation possibilities for the purge valve /flow divider assembly. Depending on the application, purge valve rotation can be CW or CCW to run the position.




APPENDIX I (Continued)

This installation has the flow divider and purge valve mounted to brackets that are supported by the push rod tubes with Adel clamps.




Installation in a Lancair 320. The horizontal mount CCW purge valve is used in this installation



A reverse offset lever (P/N 2090155) allows more clearance to the cowl.

APPENDIX I (Continued)




Purge Valve cable is supported by a bracket, which is spaced off crank case center mount bolts.


APPENDIX I (Continued)

PURGE VALVE INSTALLATION

RETURN TO VENT SYSTEM
TANK VENT LINE INTER CONNECT




APPENDIX I (Continued)
RETURN TO FUEL TANK



INTAKE MANIFOLD CONSIDERATIONS

One of the beauties of a port fuel injected engine is that the intake manifold can be optimized for acoustic tuning without the problems of wet flow. Acoustic tuning will enhance the airflow into the engine at certain RPM's. The actual calculations required for manifold design are beyond the scope of this appendix, but the following are some examples of what can be done with intake manifold design.

Acoustically tuned intake pipes are nested inside a plenum box. The pipe length is based on the RPM the engine will run and the pipe diameter is typically based upon an air velocity number. It takes all of dyno time to effectively develop a tuned intake manifold system. Obviously this type of intake manifold design will not work with a carburetor.




Injector nozzle ports.

Plenum box.

Incorporating port fuel injection to a carburetor manifold is a simple way to adapt this type of fuel metering to a number of engines. While this is not the optimum intake manifold design it does lend itself to installation versatility. A plenum box is used to collect the air after it passes through the fuel controller. This box slows the air down so that the pressure in the box is equal allowing the intake runners to pull equal air.




MAZDA INTAKE MANIFOLD DESIGN





An alternative to fabricating an intake manifold is to use the Mazda intake manifold from a 1989-1991 Mazda RX-7. This will fit Mazda rotary engines from 1986 to 1991.

MAZDA INTAKE MANIFOLD DESIGN FOR TURBO CHARGED APPLICATION




MODIFIED STOCK VW INTAKE MANIFOLD



“Y” the two intake pipes into one 2.25” diameter pipe. This can be run under the engine like the stock carburetor set-up. The fuel controller can be mounted under or behind the engine

TUNED VW INTAKE MANIFOLD




Attach fuel controller to front or rear of plenum. 2.25" tubing may be used to position the fuel controller behind or to the rear of the engine

Intake runners are 1.25" diameter. Length of the runner is 21" from the intake valve face to the bell mouth in the plenum.

Injector nozzle, 1 per cylinder. Weld a box on the intake pipe so that the nozzle will discharge fuel at the back of the intake valve.

Plenum volume is 150 to 260 cubic inches. Use rounded surfaces to keep the plenum from flexing. 1/8" aluminum is used to fabricate the box.



APPENDIX K

Supplemental Instructions for Airflow Performance

FM-100A

FM-150

FM-150C

FM-150L

FM-200A

FM-200C

FM-300B

FM-R Series

Experimental Fuel Control Units

INTRODUCTION

The following fuel control units operate on the same principle as all FM-series fuel control units. The fundamental difference these units have is the incorporation of a different designed mixture control valve. This mixture control gives very low leakage in ICO (0.0 to 8 cc/min) by effectively shutting both the metered and unmetered fuel passage to the fuel regulator section. A stainless steel plate valve running against a hard coated aluminum port bushing is used to accomplish this.

The FM-150 throttle body has the same mounting flange interface, and overall length as the Bendix RSA-5 or Precision Silver Hawk servos. The FM-150 fuel control can run engines from 150 to 260 HP.



FM-150 Fuel Control



FM-150L Fuel Control

The FM-150L is a light weight version of the FM-150. This throttle body incorporates a round flange inlet with the throttle body being approximately 0.25" shorter than the FM-150. It weighs 4.1 lbs., approximately 1 lb. lighter than the Precision Silver Hawk servo. The FM-150L fuel control can run engines from 150 to 260 HP.

INTRODUCTION




The FM-100A, FM200A and FM-300B incorporate the standard FM 100, 200 and 300 throttle body assembly while using the FM-150 regulator.



FM-200A

FM-200C

The C models of the FM-series fuel controls incorporate the same components as the FM-200A / FM-150, except throttle rotation is reversed. As with all FM series units, various parts list numbers designate different options for the fuel control. That is 90-degree inlet or outlet fitting, fitting size, mixture control rotation, etc.



FM-150C installed on IO-360M1B.

Unless otherwise noted in this Appendix refer to the main manual for all installation, adjustments, troubleshooting and maintenance.

NOTE

ALL PICTURES ARE FOR REFERENCE ONLY

SECTION 1

DESCRIPTION AND PRINCIPLES OF OPERATION

1.1. GENERAL

The FM-series fuel injection system is comprised of three basic components, a fuel metering servo, a flow divider and fuel nozzles (a nozzle in each cylinder intake port). This fuel metering system operates on a proven principle of delivering fuel in proportion to the amount of air consumed by the engine.



Figure 1.1 FM-150 Fuel System

1.2. SYSTEM DESCRIPTION

Refer to Section 1 of the manual.

1.3 MANUAL MIXTURE CONTROL

The manual mixture control valve produces a full rich condition when the lever is against the full rich (R) stop. A progressively leaner mixture is attained as the lever is moved to the “ICO” (idle cut-off) position. Moving the mixture control lever to the ICO position will effectively shut off fuel flow and stop the engine. However, the manual mixture control is not an absolute fuel shut off valve. Three to eight cc/min “leakage” is typical in the idle cut off position.



SECTION 2

INSTALLATION

2.1. FUEL PRESSURE

Typical fuel inlet pressure requirements for normal operation are 20-40 PSI. The fuel control is capable to operate at fuel pressure in the 20-80 PSI range. Maximum inlet pressure is 90 PSI.

2.2. FUEL PRESSURE GAUGE

Fuel pump output pressure is an important parameter to monitor. There are no provisions on the fuel control to pick up inlet fuel pressure. On most installations inlet fuel pressure can be measured at the outlet of the engine driven fuel pump.

2.3. FUEL FILTRATION

These fuel controls incorporate a 70 to 75 micron nominal rated composite fuel filter which can be removed for cleaning by removing the inlet fitting. This is a-relieving filter. The inlet filter fitting can be either a straight (shown) or 90-degree fitting. Cleaning the filter element is best performed in a sonic cleaner with soap and water. Blow dry with compressed air.





Figure 2.2 Fuel Inlet Filter

2.4. FUEL INLET FITTING

Fuel inlet fittings are -6 AN.

Figure 2.3
Fuel Inlet Fitting



Fuel Inlet Fitting
#6 Hose Connection
Torque hose connection
to 30-40 in.-lbs.

2.5. METERED FUEL OUTLET FITTING

The metered fuel outlet is -4 AN type fitting. It has been lock wired and sealed. This is a calibration adjustment and part of the fuel regulator. **DO NOT REMOVE THE FITTING** as this will effect calibration and proper operation of the fuel injection unit.

Metered fuel outlet fitting.
#4 hose connection.
Torque hose connection 25-35
in.-lbs.




Figure 2.4 Fuel Outlet Fitting

If the supplied metered fuel outlet will not fit in your installation contact Airflow Performance for alternate solutions for a metered fuel outlet fitting.

2.6. MANUAL MIXTURE CONTROL

The fuel control is fitted with a manual mixture control. Mixture controls can be supplied in either CW or CCW rotation to full rich. In the full rich position, the “R” stamped on the mixture control stop lever is against the plastic stop. Rotating the control to the “ICO” position will lean the mixture. “ICO” is stamped on the opposite side of the mixture control stop lever. When “ICO” is against the plastic stop, the fuel flow is shut off to the engine. There is approximately 3-8 cc/min. leakage in this position. The mixture control lever can be indexed in 15 degree increments to facilitate the linkage hook up. Make sure that the teeth on the two levers mesh correctly before tightening the lock nut. Use a 5/16 inch socket to loosen and tighten the 1/4-28 lock nut. Torque the lock nut to 50-60 in.-lbs.



WARNING

Mixture control stop screw must be lockwired. Failure to do so will result in sudden engine stoppage if the screw backs out.



Figure 2.5 Mixture Control in Rich Position

Figure 2.6 Mixture Control in ICO Position






Figure 2.7 Correctly Meshed Control Lever with Clutch Teeth

NOTE:

The manual mixture control is not intended to be used as an aircraft fuel shut off valve. If the fuel supply is near or above the level of the injector nozzles, fuel may seep into the engine, or seep out the injector nozzle vents. A zero leak fuel shut off valve should be used on these installations.

2.7 R Series Fuel Controls

R series fuel controls incorporate the light weight regulator components found in the FM-150L. These units also incorporate a fuel regulator that allows for external adjustment of the main jet setting (full throttle fuel air ratio). Typical adjustments provide approximately 1% per click to the fuel air ratio. There is an effective range of 16 clicks.



Main Jet Location
under "blue" plug.

External Adjustable Main
Jet

SECTION 3

GENERAL OPERATING INFORMATION

3.1. GENERAL

Several phases of ground operation are adversely affected by fuel vaporization in the fuel lines. Fuel vaporization may be experienced under hot conditions of ambient and/or nacelle temperatures. Starting, idle operation, and engine shut down procedures must be modified to obtain optimum results under these conditions.

3.2. STARTING

In cold weather, the engine compartment (nacelle) temperature drops off rapidly following engine shut down and the nozzle lines stay nearly full of fuel. Cold weather starting procedures are therefore simple with highly predictable results. However, in extremely hot weather, nacelle temperatures increase rapidly following engine shut down, and the fuel in the lines vaporizes and escapes out into the manifold. Hot weather starting procedures therefore depend considerably on how soon the next start is attempted. Within the first 20-30 minutes the manifold is nicely primed and the empty nozzle lines will fill before the engine quits. After a 20 to 30 minute wait, the vaporized fuel in the manifold will have nearly disappeared and some slight priming may be required to refill the nozzle lines and keep the engine running after first firing.

3.3. STARTING PROCEDURE

The following starting procedure has proven successful.

A. Cold Starts

1. Mixture control in the IDLE CUT-OFF position.
2. Set throttle to 1/2 open position.
3. Master switch -ON-.
4. Boost pump switch -ON-.
5. Move mixture control to FULL-RICH until an indication of fuel flow is seen, then immediately return the mixture control to the cut-off position.
6. Boost pump switch -OFF-.
7. Set throttle to 1/8 open

NOTE:

On installations where a fuel flow indicator is not used, allow 4 to 5 seconds in place seeing an indication of fuel flow, or turn the boost pump on until an indication of fuel pressure is observed on the inlet fuel pressure gage (15-20 PSI), put the mixture to cut-off position, then turn the pump off.

REMEMBER

With the mixture control in the rich position, fuel will flow into the engine as long as the boost pump is left on.

8. Crank engine. When engine fires, put mixture to FULL-RICH and throttle to idle.

B. Warm Starts

1. Use the same procedure as for cold starts except the boost may be left "off" and step 4, 5 and 6 eliminated. PRIME MAY NOT BE NECESSARY.

NOTE

If high under cowl temperature exist, it may be necessary to turn on the boost pump after the engine has started.

C. Flooded Starts

1. Mixture to cut-off position
2. Throttle to full open
3. Crank engine
4. When engine starts, close throttle and slowly put mixture to full rich.

3.4. IDLING

During ground operation every precaution should be taken to keep nacelle temperatures from increasing to the extent that fuel will boil and vaporize in the lines. The following suggestions are aimed at minimizing this problem:

A. Keep nacelle temperature as low as possible by:

1. Avoiding excessive ground operation.
2. Keep cooling air flow up by keeping engine RPM as high as possible.
3. Place cowl flaps in the wide open position whenever practical.
4. Upon restarting of a hot engine, operate the engine at elevated RPM'S (1200-1500 RPM) several minutes to reduce the residual heat in the engine compartment.

B. Keep fuel temperature as low as possible. Higher RPM'S with the accompanying higher line pressure and flow will help to dissipate some of the heat within the lines.

1. After restarting a hot engine, turn on the boost pump. This will pressurize the engine driven fuel pump to prevent vapor lock.
2. The boost pump should be running during take-off, before letting down for landing approach, landing and aerobatics. Under high ambient conditions it may be advisable to leave the boost pump running during taxiing to parking.

- C. Make an idle speed and mixture adjustment that is a compromise between the engine's requirement during the cool of the morning and the heat of the day.
 - 1. Adjust the idle speed to provide 700-750 RPM or as high as practical. The application the engine is used in will also determine the correct idle speed. A higher idle speed is sometimes objectionable due to its effect on landing and braking characteristics, both on roll-out and during taxiing.
 - 2. Adjust the idle mixture after the engine is to operating temperature. A slight RPM rise (10-40 RPM) may be observed when the mixture control is pulled slowly into idle cut-off.

3.5. SHUT DOWN

The idling procedure practiced just prior to engine shut down has considerable bearing on the "cleanness" or smoothness with which the engine stops. If the idling procedures above are not followed and the fuel is vaporizing and emptying the lines, the engine may continue to idle rough for a few seconds. This is despite a 100% cut-off of the fuel supply by the mixture control.

- A. Make sure the electric boost pump is turned off before attempting to shut the engine off.
- B. If required, opening the throttle with the mixture control in the idle cut-off position will aid in a cleaner shut off.
- C. Allowing the engine to run at higher RPM after prolonged idle period (1200-1500 RPM) for 10 to 15 seconds then returning the throttle to idle and stabilizing before shut down will aid in eliminating fuel vapor in the nozzle lines and improve engine shut down.
- D. Do not allow the engine to buck or "diesel" after the mixture is pulled in the ICO position. Open the throttle and turn off the mags.

3.6. SHUT DOWN PROCEDURE

1. Set propeller at minimum blade angle.
2. Idle until there is a decided decrease in cylinder head temperature.
3. Increase throttle to 1000 RPM. Maintain speed for approximately 20-30 seconds to insure adequate scavenging of the hot fuel and vapor in the nozzle lines
4. Move mixture to Idle Cut-Off.
5. When engine stops, turn ignition switch off.

SECTION 4

FIELD SERVICE

4.1. IDLE SPEED AND MIXTURE ADJUSTMENT

The following instructions deal with setting the idle mixture and speed on the engine. A preliminary idle adjustment has been set at the factory. This should be sufficient to get the engine started and running.

WARNING

THE FOLLOWING PROCEDURE IS PERFORMED WITH THE ENGINE RUNNING. THE AIRCRAFT SHOULD BE IN AN AREA THAT IS SAFE FOR RUNNING AND SECURELY TIED DOWN. USE EXTREME CAUTION WHILE WORKING AROUND RUNNING ENGINES. BE AWARE OF YOUR POSITION RELATIVE TO THE PROPELLER. IF YOU ARE UNSURE OF YOUR ABILITY TO WORK AROUND RUNNING AIRCRAFT ENGINES, DON'T ATTEMPT THIS PROCEDURE, FIND SOMEONE WHO IS QUALIFIED TO PERFORM IT FOR YOU. HAVE A QUALIFIED PERSON IN THE COCKPIT DURING THE ADJUSTMENT. DO NOT ATTEMPT THIS ADJUSTMENT ALONE. DO NOT LEAVE THE COCKPIT OR ENGINE RUNNING UNATTENDED.

- A. Warm the engine to obtain CHT and oil temperature within prescribed normal operating temperature.
- B. Make sure operating temperatures are not exceeded while running with the engine uncowl as cooling air over the engine may be decreased during ground operation.
- C. Check ignition in accordance with the instructions furnished in the aircraft or engine operational manual. If the "mag-drop" is normal, proceed with the idle adjustment.
- D. Set the idle speed with the speed stop bolt (on the throttle stop lever). Set the idle speed to the airframe manufacturer's specification, or set the idle speed as high as practical. Normal idle speed for most applications is approximately 700-750 RPM. If the RPM changes appreciably after making an idle mixture adjustment during the succeeding steps, readjust the idle speed to the desired RPM.
- E. The optimum idle setting is one that is rich enough to provide satisfactory acceleration under all conditions and lean enough to prevent spark plug fouling or rough operation.

F. The actual idle mixture adjustment is made by lengthening (rich) or shortening (lean) the linkage between the throttle stop lever and the idle lever. When it is turned out of its block, the link becomes longer and a richer idle mixture is provided. When it is turned into its block the linkage is shortened and leaner idle mixture is provided. There is a left and right hand jam nut to lock the linkage. Use two $\frac{3}{8}$ inch wrenches to make the adjustments. The left hand thread is on the throttle stop lever end. Loosen one jam nut but leave the other jam nut just snug. This will provide a little drag on the adjustment and make the adjustment easier and more accurate. Tighten both jam nuts 10-15 in-lbs. after correct idle mixture is achieved.

NOTE

Idle adjustments will not affect the wide open throttle mixture.




Figure 4-1

Idle Speed Adjustment

- H. A method for finding correct idle mixture is to check RPM rise. When the idle speed has been stabilized, move the cockpit mixture control with a very slow, smooth, steady pull into the IDLE CUT-OFF position and observe the tachometer for any change during the leaning out process. Caution must be exercised to return the mixture control to the FULL RICH position before the RPM can drop to a point where the engine cuts out. An increase in RPM while leaning out indicates the idle mixture is on the rich side of best power. An immediate decrease in RPM (if not preceded by a momentary increase) indicates that the idle mixture is on the lean side of best power. A rise of 10-40 RPM is typical with a properly adjusted mixture.
- I. Another method is to use the manifold pressure gauge. This is useful in adjusting or determining if the idle mixture is set correctly. Typically, the correct idle mixture is achieved when there is only a 0.1 to 0.3 inch of mercury drop in the MAP gauge reading with the throttle at idle and the mixture control is slowly pulled toward ICO.
- J. Each time an adjustment is made, clear the engine by running it up to 1/2 to 3/4 throttle then back to idle before making a mixture check.
- K. Changing the idle speed will affect the idle mixture. Work between the two adjustments to get the best operation.
- L. Make the final idle speed adjustment to obtain the desired idling RPM with the throttle closed.

NOTE

The idle mixture adjustment is sensitive. Do not adjust more than one to two flats at a time. Normal adjustment should not require more than one full turn in either direction.

- L. If the setting does not remain stable, check the idle linkage; any looseness in this linkage will cause erratic idling. In all cases, allowances should be made for the effect of weather conditions upon idling adjustments. The relationship of the aircraft to the direction of the prevailing wind will have an effect on the propeller load and its RPM; hence it is advisable to make the idle setting with the aircraft cross-wind.
- M. Idle speed and mixture adjustments made according to this method should require little attention except for extreme variations in temperature and altitude.
- N. Erratic idle may be encountered under prolonged idle or high under cowl temperatures. Running the engine up briefly will clear the hot fuel from the nozzle lines.
- O. If while adjusting the idle mixture it seems that the idle mixture is erratic or the adjustment seems to be chased, try running the boost pump, clear out the engine and continue with the idle mixture adjustment procedure with the boost pump on.

4-2. FULL THROTTLE MIXTURE ADJUSTMENT

The following instructions deal with the full throttle mixture. An EGT (exhaust gas temperature) gauge and fuel flow meter is highly advisable to determine the correct mixture strength. The fuel air ratio in your fuel control has been set at the factory for flow limits established for the engine model.

WARNING

THE FOLLOWING PROCEDURE REQUIRES THAT THE ENGINE BE OPERATED UNDER FULL POWER. THE AIRCRAFT MUST BE IN AN AREA SUITABLE FOR FULL THROTTLE RUN-UP. THE AIRCRAFT MUST BE CHOCKED AND TIED DOWN SECURELY. DO NOT RELY ON THE AIRCRAFT BRAKES TO HOLD THE AIRCRAFT DURING THIS TEST. OBSERVE ENGINE OPERATING TEMPERATURES AND OPERATION DURING FULL THROTTLE. IF ANY TEMPERATURES OR PARAMETERS ARE EXCEEDED OR ENGINE OPERATION IS NOT NORMAL OR ERRATIC, IMMEDIATELY DISCONTINUE FULL THROTTLE OPERATION.

- A. Bring the engine up to operating temperature.
- B. Put the mixture control to the FULL RICH position.
- C. Advance the throttle to wide open.
- D. Observe the RPM, MAP and EGT. These parameters must be within the engine model specifications.
- E. If the full rich full throttle mixture is not correct, it can be made by changing the main jet




Figure 4-2.

WARNING

PROCEDURES PERFORMED WHILE THE ENGINE IS RUNNING REQUIRE EXTREME CAUTION. BE AWARE AT ALL TIMES OF YOUR POSITION RELATIVE TO THE PROPELLER. HAVE A QUALIFIED PERSON IN THE COCKPIT AT ALL TIMES WHILE THE ENGINE IS RUNNING. DO NOT LEAVE AN ENGINE RUNNING UNATTENDED.

- F. Observe the RPM and EGT. These parameters must be within the engine manufactures specifications. Typical full throttle EGT for Lycoming engines is 1300 to 1375 degrees Fahrenheit. On most 4-stroke engines, correct full rich mixture is indicated by an increase of 25 to 50 RPM when the mixture is manually leaned while at full throttle and the engine is equipped with a fixed pitch propeller.
- G. Typical correct fuel mixture can also be determined by the change in EGT from peak to full rich. With a power setting of 2400 RPM and 24" MAP lean the mixture until one of the cylinder's peaks in EGT. Record that number then return the mixture to full rich. When the EGT has stabilized on that cylinder, record the EGT reading. The difference in the two readings should be 185-225 degrees F. If the change is less than 185 then it indicates that the mixture is lean. Alternately a difference of more than 225 degrees indicated a rich mixture. Readings should be taken at altitudes below 4000 feet.
- H. If the full rich full throttle mixture is not correct, it can be adjusted by changing the main jet located inside the fuel controller. See Figure 4-2.
- I. Main jets are precision flowed parts, and can be purchased from Airflow Performance. Jets are sized like number drills (a #48 is leaner than a #46) and are also available in half sizes. Use extreme caution when removing or installation the main jet. Be careful not to chip or allow the screw driver to slip on the jet. Do not over tighten the jet when reinstalling. Apply some oil to the O-rings when reinstalling the fittings.
- J. Re-lock-wire the #4 plug after changing the main jet.
- K. If there is no change in fuel flow with an adjustment of the main jet, other problems exist in the fuel system. Discontinue making adjustments to this feature and refer to the trouble-shooting section of this manual.
- L. The above are guidelines only. Engine full rich mixture requirements will vary from engine to engine due to engine design and air inlet configurations. Contact Airflow Performance and or the engine manufacture before making a main jet change.

SECTION 5

TROUBLE-SHOOTING

5.1. GENERAL

Refer to Section 6 of the manual

5.2. MANUAL MIXTURE CONTROL LEAKAGE TEST

The following procedure will test for correct operation of the manual mixture control. The Manual Mixture Control on FM fuel control in the idle cut-off position will only reduce the fuel flow sufficiently to stop the engine. It is not a zero leak valve. It is not intended as a fuel shut off valve.

- A. Disconnect the hose that attaches to the flow divider (metered fuel hose). Leave the hose attached to the fuel control.
- B. Place the hose in a suitable container.
- C. Turn the boost pump on and put the mixture control to Full Rich. Open the throttle wide open.
- D. Observe the fuel flowing from the metered fuel hose; now close the throttle to idle. The fuel flow should decrease to a lower level. Insure that all the air has been purged from the fuel control. There should be no air bubbles observed in the fuel stream.
- E. Put the manual mixture control in Idle Cut-Off (ICO).
- F. The fuel flow should decrease to a slow drip (3-8 cc's per minute).

If the fuel control does not perform as described in the above procedure, there is excessive leakage around the manual mixture control. Return the fuel control for repair.

THIS PAGE INTENTIONALLY LEFT BLANK